JVC

SERVICE MANUAL

AUDIO/VIDEO CONTROL RECEIVER

RX-8010RBK
RX-8012RSL

Area Suffix

E ------- Continental Europe
EN -------- Northern Europe





TEXT COMPU LINK

DIGITAL dts SURROUND

DOLBY DIGITAL

RIDISI

Contents

Safety precautions ----------1-2
Disassembly method ----------1-3
Adjustment method ----------1-9
Self-diagnose function ----------1-10
Description of major ICs ----------1-12~29

COPYRIGHT © 2001 VICTOR COMPANY OF JAPAN, LTD.

No.20979
May. 2001

Safety Precautions

1. This design of this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Services should be performed by qualified personnel only.
2. Alterations of the design or circuitry of the product should not be made. Any design alterations of the product should not be made. Any design alterations or additions will void the manufacturer`s warranty and will further relieve the manufacture of responsibility for personal injury or property damage resulting therefrom.
3. Many electrical and mechanical parts in the products have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the Parts List of Service Manual. Electrical components having such features are identified by shading on the schematics and by (⚠) on the Parts List in the Service Manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement parts shown in the Parts List of Service Manual may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps, tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and/or sharp edges for the prevention of electric shock and fire hazard. When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after re-assembling.
5. Leakage currnet check (Electrical shock hazard testing)
   After re-assembling the product, always perform an isolation check on the exposed metal parts of the product (antenna terminals, knobs, metal cabinet, screw heads, headphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock.
   Do not use a line isolation transformer during this check.
   - Plug the AC line cord directly into the AC outlet. Using a "Leakage Current Tester", measure the leakage current from each exposed metal parts of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground. Any leakage current must not exceed 0.5mA AC (r.m.s.).
   - Alternate check method
     Plug the AC line cord directly into the AC outlet. Use an AC voltmeter having, 1,000 ohms per volt or more sensitivity in the following manner. Connect a 1,500Ω 10W resistor paralleled by a 0.15μF AC-type capacitor between an exposed metal part and a known good earth ground.
     Measure the AC voltage across the resistor with the AC voltmeter.
     Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and meausre the AC voltage across the resistor. Now, reverse the plug in the AC outlet and repeat each measurement. Voltage measured any must not exceed 0.75 V AC (r.m.s.). This corresponds to 0.5 mA AC (r.m.s.).



Warning

1. This equipment has been designed and manufactured to meet international safety standards.
2. It is the legal responsibility of the repairer to ensure that these safety standards are maintained.
3. Repairs must be made in accordance with the relevant safety standards.
4. It is essential that safety critical components are replaced by approved parts.
5. If mains voltage selector is provided, check setting for local voltage.

⚠ CAUTION

Burrs formed during molding may be left over on some parts of the chassis. Therefore, pay attention to such burrs in the case of preforming repair of this system.

In regard with component parts appearing on the silk-screen printed side (parts side) of the PWB diagrams, the parts that are printed over with black such as the resistor (▬), diode (▮) and ICP (●) or identified by the "⚠" mark nearby are critical for safety.
When replacing them, be sure to use the parts of the same type and rating as specified by the manufacturer. (Except the JC version)

Disassembly method

■Removing the top cover (See Fig.1)

1. Remove the four screws A attaching the top cover on both sides of the body.
2. Remove the three screws B on the back of the body.
3. Remove the top cover from behind in the direction of the arrow while pulling both sides outward.



Fig.1

■Removing the front panel assembly (See Fig.2 and 3)

・Prior to performing the following procedure, remove the top cover.

1. Disconnect the card wire from connector CN400 on the audio board and CN402 on the power supply board in the front panel assembly.
2. Cut off the tie band fixing the harness.
3. Remove the three screws C attaching the front panel assembly.
4. Remove the four screws D attaching the front panel assembly on the bottom of the body. Detach the front panel assembly toward the front.



Fig.2



Fig.3

■Removing the rear panel (See Fig.4)

・Prior to performing the following procedure, remove the top cover.

1. Remove the power cord stopper from the rear panel by moving it in the direction of the arrow.
2. Remove the thirty one screws E attaching the each boards to the rear panel on the back of the body.
3. Remove the three screws F attaching the rear panel on the back of the body.



Fig.4

■Removing each board connected to the rear side of the audio board

(See Fig.5 to 11)

- Prior to performing the following procedure, remove the top cover and the rear panel.

1. Cut off the tie band fixing the harness.
2. Extract the plastic rivet **a**, which prevents the PWB from pulling out, from the audio input board.
3. Disconnect the connect CN501, CN243, CN205, CN381, CN361 on the DVD board.
4. Disconnect the harness from connector CN721, CN722 and CN723.
5. Disconnect the tuner board and audio board from connector CN101, CN102 and CN301 on the audio board.
6. Pull out the video audio board, video board, S-video board.
7. Disconnect the DSP board from connector CN601 on the audio board.



Fig.5



Fig.6



Fig.7



Fig.8



Fig.9



Fig.10



Fig.11

■ Removing the audio board (See Fig.12 and 13)

- Prior to performing the following procedure, remove the top cover and the rear panel.

1. Disconnect the harness from connector CN813 and CN814 on the main board.
2. Disconnect the card wire from connector CN931 and CN932 on the audio board.
3. Cut off the tie band fixing the harness.
4. Disconnect the relay board from the audio board and the power supply board. (CN71,CN81)
5. Disconnect the card wire from connector CN831 on the main board.
6. Remove the three screws G attaching the audio board assembly.
7. Remove the screw H attaching the audio board assembly.



Fig.12



Fig.13

■Removing the main board (See Fig.14)

・Prior to performing the following procedure, remove the top cover, the rear panel and audio board.

1. Cut off the tie band fixing the harness.
2. Disconnect the harness from connector CN811 on the power supply board respectively.
3. Disconnect the harness from connector CN881 on the main board.
4. Remove the four screws I and the two screws J attaching the main board.



Fig.14

■Removing the Heat sink (See Fig.15 and 16)

1. Remove the two screws L' attaching the heat sink from the rear side of main board.
2. Disconnect the connect CN701, CN702, CN703, CN705 and CN706 on the main board.
3. Remove the ten screws K and four screws L attaching the heat sink.



Fig.15



Fig.16

■Removing the power transformer (See Fig.17)

- Prior to performing the following procedures, remove the top cover.

1. Unsolder the two harnesses connected to the power transformer.
2. Disconnect the harness from connector CN55 and CN56 on the power transformer board.
3. Remove the four screws M attaching the power transformer.

■Removing the power / fuse board (See Fig.17)

- Prior to performing the following procedure, remove the top cover and the rear panel.

1. Remove the screw N attaching the power / fuse board.
2. Unsolder the power cord and other harnesses connected to the power / fuse board.



Fig.17

■Removing the power supply board (See Fig.18 and 19)

- Prior to performing the following procedure, remove the top cover and the front panel.

1. Remove the screws **b** fixing a bonding ground.
2. Remove the one nut attaching the headphone jack of the power supply board on the front side of the body.
3. Disconnect the card wire from connector CN402 on the power supply board.
4. Remove the three screws O attaching the power supply board and pull out the power supply board from the front bracket backward.
5. Unsolder the three harnesses connected to the power supply board.



Fig.18



Fig.19

■Removing the system control board / power switch board (See Fig.20 to 22)

・Prior to performing the following procedure, remove the top cover and the front panel assembly.

1. Pull out the volume knob on the front side of the front panel and remove the nut attaching the system control board.
2. Remove the two screws P attaching the power switch board.
3. Remove the two screws Q attaching the switch board.
4. Remove the cords from the three hooks **a**.
5. Remove the eight screws R attaching the system control board on the back of the front panel.
6. On the back of the front panel, release the four joints by pushing the joint tabs inward.
   Remove the operation switch panel toward the front.
7. Disconnect the harness from connector CN420 and CN422 on the system control board.
8. Release the two hooks **b** attaching the system control board.



Fig.20



Fig.21



Fig.22

■Matters that require attention during replacement of IC400 (See Fig.24 and 25)

・In case where there is a resistance array:
Both onetime IC and mask IC can be used

・In case where there is no resistance array:
Only mask IC can be used



Fig.24



Fig.25

Adjustment method

■ Tuner section

1.Tuner range

FM	87.5MHz~108.0MHz
AM(MW)	522kHz~1629kHz
(LW)	144kHz~288kHz

■ Power amplifier section

Adjustment of idling current

Measurement location	B2204-B2205(Lch) , B2213-2214(Rch)
Adjustment part	VR787(Lch) , VR788(Rch)

Attention
This adjustment does not obtain a correct adjustment value immediately after the amplifier is used (state that an internal temperature has risen).
Please adjust immediately after using the amplifier after turning off the power supply of the amplifier and falling an internal temperature.

<Adjustment method>

1.Set the volume control to minimum during this adjustment.(No signal & No load)
2.Set the surround mode OFF.
2.Turn VR787 and VR788 fully counterclockwise to warm up before adjustment.
If the heat sink is already warm from previous use the correct adjustment can not be made.
3.For L-ch,connect a DC voltmeter between B2204 and B2205 (Lch)
And,connect it between B2213 and B2214(Rch).
4.30 minutes later after power on, adjust VR787 for L-ch, or VR788 for R-ch so that the DC voltmeter value has 1mV~10mV.

* It is not abnormal though the idling current might not become 0mA even if it is finished to turn variable resistance (VR787,VR788) in the direction of counterclockwise.



Self-diagnose function

1. Detection of abnormal power supply and voltage

- When the power is turned ON, if an abnormality is detected during the signal input at the A/D port (IC901, pin 2-5, 7) for one second continuously, the status will become STANDBY mode immediately.

- When the power is turned ON again, detection of abnormal power supply and voltage will not be carried out during the first 4 seconds.

- Given below is a list of threshold values at the detection of abnormalities.

	At abnormal state (Low voltage)	At normal state	At abnormal state (High voltage)
Pin 2 Micro-computer+5V	Analog value 0 - 2.2V	Analog value 2.2 - 2.8V	Analog value 2.8 - 5.0V
Pin 3 Digital+5V	Analog value 0 - 2.2V	Analog value 2.2 - 2.8V	Analog value 2.8 - 5.0V
Pin 4 Analog+5V	Analog value 0 - 2.2V	Analog value 2.2 - 2.8V	Analog value 2.8 - 5.0V
Pin 5 +12V	Analog value 0 - 2.2V	Analog value 2.2 - 2.8V	Analog value 2.8 - 5.0V
Pin 7 Tuner+9V	Analog value 0 - 2.2V	Analog value 2.2 - 2.8V	Analog value 2.8 - 5.0V

2. Initial setting on ship

- To gain the initial setting on ship, put the power plug in the socket while pressing DOWN key and UP key together simultaneously, then turn the power ON.

3. Test mode

- To enter the test mode, put the power plug in the socket while pressing EFFECT key and UP key together simultaneously, then turn the power ON.

- Workings of test mode:
  ① All FLs are turned ON for 3 seconds. (the FLs, which are divided in two groups, are turned ON alternatively)
  ② Faster volume UP/DOWN operation can be achieved with the remote controller.

- When the power is turned OFF, the test mode will be released.

- The FL display returns to normal after the three seconds. Then the STANDBY LED is turned ON (flashing ON and OFF for each one second) to show the present status being a test mode.

4. Self-diagnose

- To enter the self-diagnose mode, put the power plug in the socket while pressing SETTING key and UP key together simultaneously, then turn the power ON. With the UP/DOWN key operation, DSP microcomputer, ROM No.of system microcomputer as well as working status of DSP can be displayed for five seconds. While the working status is being displayed, the followings items can be switched with the UP/DOWN key operation.

  VERSION of system microcomputer → Local microcomputer CH0 →
  Local microcomputer CH01 → Local microcomputer CH2 →
  Local microcomputer CH3 → Local microcomputer CH4

- When the power is turned OFF, the self-diagnose mode will be released.
- During the self-diagnose mode, the STANDBY LED is turned ON .
  (flashing ON for one second then OFF for three seconds)
- FL transient display will be carried out as follows. When the transient display is not carried out, normal display/workings are carried out.



Upper 1 2 3 4 5 digits
Lower 1 2 3 4 5 6 7 8 9 10 digits

FL Display

S 0 0 1 1
2 0 0 0 1 2 0 9 0 0 ・ Information on VERSION of system microcomputer (IC901)
Example : VER1.1 2000/12/9

↓

D 0 0 □ □
□□□□□□□□□□ ・ Display of communication information on DSP microcomputer (IC581)

↓

D 0 1 □ □
□□□□□□□□□□ ・ Display of communication information on DIR AK4112A (IC551)

↓

D 0 2 □ □
□□□□□□□□□□ ・ Display of communication information on DSP XCA56367 (IC501)

↓

D 0 3 □ □
□□□□□□□□□□ ・ Display of communication information on CODEC AK4527 (IC571)

↓

D 0 4 1 1
2 0 0 0 1 2 0 9 0 0 ・ Information on VERSION of DSP microcomputer (IC581)
Example :VER1.1 2000/12/9

Description of major ICs

■ AK4112AVF (IC551) : Digital audio receiver

1.Pin layout



2.Pin function

No.	Pin Name	I/O	Function
1	DVDD	-	Digital power supply pin, 3.3V
2	DVSS	-	Digital ground pin
3	TVDD	-	Input buffer power supply pin, 3.3V or 5V
4	V	O	Validity flag output pin in Parallel Mode
	TX	O	Transmit channel (through data) output pin in Serial Mode
5	XTI	I	X'tal input pin
6	XTO	O	X'tal output pin
7	PDN	I	Power-down mode pin When "L", the AK4112A is powerd-down and reset.
8	R	-	External resistor pin 18kΩ +/-1% resistor to AVSS externally.
9	AVDD	-	Analog power supply pin
10	AVSS	-	Analog ground pin
11	RX1	I	Receiver channel 1 This channel is selected in Parallel Mode or default of Serial Mode.
12	DIF0	I	Audio data interface format 0 pin in Parallel Mode
	RX2	I	Receiver channel 2 in Serial Mode
13	DIF1	I	Audio data interface format 1 pin in Parallel Mode
	RX3	I	Receiver channel 3 in Serial Mode
14	DIF2	I	Audio data interface format 2 pin in Parallel Mode
	RX4	I	Receiver channel 4 in Serial Mode
15	AUTO	O	Non-PCM detect pin "L" : No detect, "H" : Detect
16	P/S	I	Parallel/ Serial select pin "L" : Serial Mode, "H" ; Parallel Mode
17	FS96	O	96kHz sampling detect pin (RX Mode) "H" : fs=88.2kHz or more, "L" fs=54kHz or less. (X'tal Mode) "H" : XFS96=1, "L" : XFS96=0.
18	ERF	O	Unlock & parity error output pin "L" : No error, "H" : Error
19	LRCK	I/O	Output channel clock pin
20	SDTO	O	Audio serial data output pin
21	BICK	I/O	Audio serial data clock pin
22	DAUX	I	Auxiliary audio data input pin
23	MCK02	O	Master clock #2 output pin
24	MCK01	O	Master clock #1 output pin
25	OCKS0	I	Output clock select 0 pin in Parallel Mode
	CSN	I	Chip select pin in Serial Mode
26	OCKS1	I	Output clock select 1 pin in Parallel Mode
	CCLK	I	Control data clock pin in Serial Mode
27	CM1	I	Master clock operation Mode pin0 in Parallel Mode
	CDTI	I	Control data input pin in Serial Mode
28	CM0	I	Master clock operation Mode pin1 in Parallel Mode
	CDTO	O	Control data output pin in Serial Mode

Note 1 : All input pins except internal pull-down pins should not be left floating.

■ AK4527 (IC571) : A/D,D/A Converter

1.Pin layout



2.Block diagram



Block Diagram (DIR and AC-3) DSP are external parts)

3. Pin function

AK4527(1/2)

No.	Pin name	I/O	Function
1	SDOS	I	SDTO Source select pin "L" : Internal ADC output, "H" : DAUX input ORed with serial control register if P/S="L".
2	OCKS	I	MCKO Clock frequency select pin "L" : MCLK, "H" : MCLK/2. ORed with serial control register if P/S= "L".
3	MIS	I	Connect to GND
4	BICK	I	Audio serial data clock pin
5	LRCK	I/O	Input/Output channel clock pin
6	SDTI1	I	DAC1 Audio serial data input pin
7	SDTI2	I	DAC2 Audio serial data input pin
8	SDTI3	I	DAC3 Audio serial data input pin
9	SDTO	O	Audio serial data output pin
10	DAUX	I	AUX Audio serial data input pin
11	DFS	I	Double speed sampling mode pin "L" : Normal speed, "H" : Double speed, the ADC is powered down. ORed with serial control register if P/S="L".
12	DEM1	I	De-emphasis pin ORed with serial control register if P/S="L"
13	DEM0	I	De-emphasis Pin ORed with serial control register if P/S="L"
14	MCKO	O	Master clock output pin
15	DVDD	-	Digital power supply pin
16	DVSS	-	Digital ground pin
17	$\overline{PD}$	I	Power-down & Reset pin When "L", the AK4527 is powered-down and the control registers are reset to default state. If the state of CAD0-1 changes, then the AK4527 must be reset by PDN.
18	ICKS2	I	Input clock select 1 pin
19	ICKS1	I	Input clock select 1 pin
20	ICKS0	I	Input clock select 0 pin
21	CAD1	I	Chip address pin
			Used during the serial control mode.
22	CAD0	I	Chip address pin Used during the serial control mode.
23	LOUT3	O	Lch #3 analog output pin
24	ROUT3	O	Rch #3 analog output pin
25	LOUT2	O	Lch #2 analog output pin
26	ROUT2	O	Rch #2 analog output pin
27	LOUT1	O	Lch #2 analog output pin
28	ROUT1	O	Rch #1 analog output pin
29	LIN-	I	Lch analog negative Input Pin
30	LIN+	I	Lch analog positive Input Pin
31	RIN-	I	Rch analog negative Input Pin
32	RIN+	I	Rch analog positive Input Pin

3.Pin function

AK4527(2/2)

No.	Pin Name	I/O	Function
33	VREFL	I	Negative voltage reference Input pin, AVSS
34	VCOM	O	Common voltage output pin,AVDD/2 Large external capacitor around 2.2uF is used to reduce power-supply noise
35	VREFH	I	Positive voltage reference input pin,AVDD
36	AVDD	-	Analog power supply pin
37	AVSS	-	Analog ground pin
38	XTI	I	X'tal input pin
39	XTO	O	X'tal output pin if XTS="H"
	MCKI	I	External master clock input pin if XTS="L"
40	P/S	I	Parallel/Serial select pin "L" : Serial control mode, "H" : Parallel control mode
41	DIF0	I	Audio data interface format pin in parallel mode
	$\overline{CS}$	I	Chip select pin in serial mode
42	DIF1	I	Audio data interface format pin in parallel mode
	CCLK	I	Control data clock pin in serial mode
43	LOOP0	I	Loop back mode pin in parallel mode Enables digital loop-back from ADC to 3 DACs.
	CDTI	I	Control data input pin in serial mode
44	LOOP1	I	Loop back mode pin in parallel mode Enable all 3 DAC channels to be input from SDTII.
	CDTO	O	Control data output pin in serial mode

■ BA15218F (IC303, IC304, IC372, IC385, IC386, IC521, IC522, IC523, IC524, IC525, IC526, IC527, IC528, IC529) : Op amp.



■ BA7625 (IC201, IC242) : Video selector



A	B	E	MONITOR OUT
L	L	*	IN1
H	L	*	IN2
L	H	*	IN3
H	H	L	IN4
H	H	H	IN5

C	D	E	VOUT1
L	L	*	--
H	L	*	IN2
L	H	*	IN3
H	H	L	IN4
H	H	H	IN5

C	D	E	VOUT2
L	L	*	IN1
H	L	*	--
L	H	*	IN3
H	H	L	IN4
H	H	H	IN5

■ BA7626 (IC241) : Video selector



A	B	E	MONITOR OUT
L	L	*	IN1
H	L	*	IN2
L	H	*	IN3
H	H	L	IN4
H	H	H	IN5

C	D	E	VOUT1
L	L	*	--
H	L	*	IN2
L	H	*	IN3
H	H	L	IN4
H	H	H	IN5

C	D	E	VOUT2
L	L	*	IN1
H	L	*	--
L	H	*	IN3
H	H	L	IN4
H	H	H	IN5

■ BU2092(IC402) : Port expander

1.Terminal Layout



2.Pin Function

Pin No.	Symbol	I/O	Function
1	Vss	-	Connect to GND
2	DATA	I	Serial Data input
3	CLOCK	I	Shift Clock of Data
4	LCK	I	Latch Clock of Data
5~16	Q0~Q11	O	Parallel Data Output Latch Data: L / H OUTPUT: ON / OFF
17	$\overline{OE}$	I	Output Enable
18	Vdd	-	Power Supply

■ LA1838(IC102) : FM AM IF AMP&detector, FM MPX decoder

1. Block Diagram



2. Pin Function

Pin No.	Symbol	I/O	Function	Pin No.	Symbol	I/O	Function
1	FM IN	I	This is an input terminal of FM IF signal.	16	L OUT	O	Left channel signal output.
2	AM MIX	O	This is an out put terminal for AM mixer.	17	R OUT	O	Right channel signal output.
3	FM IF	I	Bypass of FM IF	18	L IN	I	Input terminal of the left channel post AMP.
4	AM IF	I	Input of AM IF Signal.	19	R IN	I	Input terminal of the right channel post AMP.
5	GND	—	This is the device ground terminal.	20	RO	O	Mpx Right channel signal output.
6	TUNED	O	When the set is tuning, this terminal becomes "L".	21	LO	O	Mpx Left channel signal output.
7	STEREO	O	Stereo indicator output. Stereo "L", Mono: "H"	22	IF IN	I	Mpx input terminal
8	VCC	—	This is the power supply terminal.	23	FM OUT	O	FM detection output.
9	FM DET	—	FM detect transformer.	24	AM DET	O	AM detection output.
10	AM SD	—	This is a terminal of AM ceramic filter.	25	AM AGC	I	This is an AGC voltage input terminal for AM
11	FM VSM	O	Adjust FM SD sensitivity.	26	AFC	—	This is an output terminal of voltage for FM-AFC.
12	AM VSM	O	Adjust AM SD sensitivity.	27	AM RF	I	AM RF signal input.
13	MUTE	I/O	When the signal of IF REQ of IC121(LC72131) appear, the signal of FM/AM IF output. //Muting control input.	28	REG	O	Register value between pin 26 and pin28 desides the frequency width of the input signal.
14	FM/AM	I	Change over the FM/AM input. "H" :FM, "L" : AM	29	AM OSC	—	This is a terminal of AM Local oscillation circuit.
15	MONO/ST	O	Stereo : "H", Mono: "L"	30	OSC BUFFER	O	AM Local oscillation Signal output.

■ MB90088 (IC203) : On screen display controller

1.Terminal Layout



2.Block Diagram



3.Functions

pin no	Symbol	I/O	Function
1	YIN	I	Lux signal Input terminal for Superinpause indication
2	VIN	I	Composite video signal input terminal for Superinpause indication
3	CIN	I	Contrast signal input terminal for Superinpause indication
4	AVcc	-	Analog power supply terminal
5	IOUT	O	Color (Lux) signal output terminal
6	VOC	O	Character output terminal
7	Vcc	-	Power supply terminal
8	EXS	I	Clock generater outside circuit terminal for color burst
9	XS	O	
10	$\overline{\text{HSYNC}}$	O	Horizontal signal output terminal
11	$\overline{\text{VSYNC}}$	O	Vertical signal output terminal
12	$\overline{\text{EXHSYN}}$	I	EXT horizontal signal input terminal
13	$\overline{\text{EXVSYN}}$	I	EXT vertical signal input terminal
14	Vss	-	GND
15	EXD	I	Dot clock generater outside circuit signal terminal for indication
16	XD	O	
17	VOB	O	Character & background signal output terminal
18	GOUT	O	Color signal (Green, Red, Blue)
19	ROUT		
20	BOUT		
21	$\overline{\text{TEST}}$	I	Test signal input terminal
22	SCLK	I	Shift clock input terminal for serial transmission
23	SIN	I	Serial data input terminal
24	$\overline{\text{CS}}$	I	Chip select terminal
25	COUT	O	Contrast signal output terminal
26	VOUT	O	Composite video signal output terminal
27	YOUT	O	Lux signal output terminal
28	AVss	-	Analog GND terminal

■NJM2285V-W(IC202) : 2-Input 3channel VIDEO switch



■ NJM4580DD (IC301) : LPF, Mic and H.phone Amp.

1.Terminal layout



(TOP VIEW)

2.Block diagram



■ NJU7241F33(IC411) : Voltage regulator



PIN FUNCTION
1. GND
2. V_{IN}
3. V_{OUT}
4. +NC
5. STB

■ PCM2702E-X (IC410) : Digtal / Analog converter

1.Pin layout



2. Block diagram



3.Pin function

PIN	Symbol	I/O	Function
1	XTI	IN	Crystal Oscillator Input. (1)
2	VDDC	-	Digital Power Supply for Clock Generator, +3.3V.
3	DGNDC	-	Digital Ground for Clock Generator.
4	VDD	-	Digital Power Supply, +3.3V.
5	DGND	-	Digital Ground.
6	D+	I/O	USB Differential Input/Output Plus.
7	D-	I/O	USB Differential Input/Output Minus.
8	VBUS	IN	USB Bus Power (This pin NEVER consumes the USB bus power). (2)
9	DGNDU	-	Digital Ground for USB Transceiver.
10	$\overline{\text{PLYBCK}}$	OUT	Playback flag, active LOW. (LOW: playback, HIGH: idle).
11	$\overline{\text{SSPND}}$	OUT	Suspend flag, active LOW. (LOW: suspend, HIGH: operational).
12	ZERO	OUT	Zero flag, (LOW: Normal, HIGH: ZERO).
13	TEST3	IN	Test pin 3. Connect to digital ground. (2)
14	TEST2	IN	Test pin 2. Connect to digital ground. (2)
15	TEST1	IN	Test pin 1. Connect to digital ground. (2)
16	TEST0	IN	Test pin 0. Connect to digital ground. (2)
17	VccR	-	Analog Supply for R-channel, +5V.
18	AGNDR	-	Analog Ground for R-channel.
19	VOUTR	OUT	Analog Output for R-channel.
20	AGND	-	Analog Ground.
21	VCOM	-	Common for DAC.
22	Vcc	-	Analog Supply, +5V.
23	VOUTL	OUT	Analog output for L-channel.
24	AGNDL	-	Analog Ground for L-channel.
25	VccL	-	Analog Supply for L-channel, +5V.
26	AGNDP	-	Analog Ground for PLL.
27	VccP	-	Analog Supply for PLL, +5V.
28	XTO	OUT	Crystal Oscillator Output.

Note:
(1) 3.3V tolerant.
(2) Schmitt trigger input with internal pull-down, 5V tolerant.

■ SAA6588 (IC191) : RDS detector

1.Terminal Layout

2.Pin Function

Pin No.	Symbol	I/O	Function
1	MRO	O	Multi-path rectifier output
2	MPTH	-	Multi-path detector output
3	TCON	I	Test control input pin
4	OSCO	O	Oscillator output
5	OSCI	I	Oscillator input
6	VSSD	-	Digital ground (0V)
7	VDDD	-	Digital power supply (5V)
8	DAVN	O	Data available output (active LOW)
9	SDA	I/O	IC-bus serial data I/O
10	SCL	I	IC-bus serial clock input
11	PSWN	-	Pause switch output (active LOW)
12	MAD	-	Slave addrese (LSB) input
13	AFW	-	Audio signal input
14	VDDA	-	Analog power supply (5V)
15	VSSA	-	Connect to ground
16	MPX	I	Multiplex input signal
17	Vref	O	Reference voltage output
18	SCOUT	O	Band-pass filter output
19	CIN	O	Comparator output
20	LVIN	I	Level input

3.Block Diagram



■ TC9162AN (IC380) : Analog switch





■TC9163AF-X (IC371) : Analog switch





■ TC9164AF-X (IC302) : Analog switch





■ TC9459F (IC381, IC382, IC383) : Electronic volume control

1.Terminal layout



2. Block diagram



3.Pin function

Pin No.	Symbol	Function	Pin No.	Symbol	Function
1	VSS	Negative power supply pin	13	DATA	Data input pin
2	L-OUT	Volume output pin	14	STB	Strobe input pin
3	NC	No connection	15	NC	No connection
4	NC	No connection	16	CS2	Chip select input pin
5	L-LD1	Loudness tap output pin	17	NC	No connection
6	L-LD2	Loudness tap output pin	18	R-A-GND	Analog GND pin
7	L-A-GND	Analog GND pin	19	R-LD2	Loudness tap output pin
8	NC	No connection	20	R-LD1	Loudness tap output pin
9	CS1	Chip select input pin	21	R-IN	Volume input pin
10	NC	No connection	22	NC	No connection
11	GND	Digital GND pin	23	R-OUT	Volume output pin
12	CK	Clock input pin	24	VDD	Positive power supply pin

■ TC7S04FU (IC502, IC503) :CMOS Inverter



■ TC7SET32FU (IC582) : Z-Input or gate





■ W24L010AJ-12 (IC511) : CMOS static RAM

1. Pin layout



2. Block diaglam



3. Pin function

SYMBOL	DESCRIPTION
A0 - A16	Address Input
I/O1 - I/O8	Data Input/Output
$\overline{CS1}$, CS2	Chip Select Inputs
$\overline{WE}$	Write Enable Input
$\overline{OE}$	Output Enable Input
VDD	Power Supply
Vss	Ground
NC	No Connection

■ UPD784215AGC132(IC581) : Unit CPU

1.Pin layout



2.Pin function

Pin No.	Symbol	I/O	Function
1~8		-	Non connect
9	VDD	-	Power supply terminal
10	X2	-	Connecting the crystal oscillator for system main clock
11	X1	I	Connecting the crystal oscillator for system main clock
12	VSS	-	Connect to GND
13	XT2	-	Connecting the crystal oscillator for system sub clock
14	XT1	I	Connect VSS
15	$\overline{\text{RESET}}$	I	System reset signal input
16	AUTO	I	Output of DSP to general-purpose port
17	ERR	I	Output of DSP to general-purpose port
18	Fz96k	I	Output of DSP to general-purpose port
19~22	P03~P06	I	Output of DSP to general-purpose port
23	AVDD	-	Power supply terminal
24	AV REF0	-	Connect to GND
25~32	P10~P17	-	Connect to GND
33	AVSS	-	Connect to GND
34,35	P130, P131	O	Non connect
36	AV REF1	-	Power supply terminal
37,38	RX, TX	O	Not use
39		O	Non connect
40	DSPCOM	I	Communication port from IC901
41	DSPSTS	O	Status communication port to IC901
42	DSPCLK	I	Clock input from IC901
43	DSPRDY	I	Ready signal input from IC901
44		O	Non connect
45,46	MIDIO_IN/OUT	I/O	Interface I/O terminal with microcomputer
47	$\overline{\text{MICK}}$	O	Interface I/O terminal with microcomputer of clock signal
48	HREQ	I	HREQ
49	SS	O	System slave select
50,51		-	Non connect
52	$\overline{\text{DSP_RST}}$	O	Reset signal output of DSP
53		-	Non connect
54	$\overline{\text{D_CS}}$	O	Chip setselct output
55		-	Non connect
56	PD/ DIR	O	Reset signal output
57~63		-	Non connect
64,65	CDTI/CDTO	O/I	Interface I/O terminal with microcomputer
66	$\overline{\text{CCLK}}$	O	Interface I/O terminal with microcomputer of clock signal
67	$\overline{\text{CS}}$	O	CS
68~70		-	Non connect
71	$\overline{\text{PD}}$	O	Reset signal output
72	GND	-	Connect to GND
73~75		-	Non connect
76	EQ	O	EQ
77	CTR TONE	O	CENTER TONE
78	3D	O	3D-Phonic
79,80		-	Non connect
81	VDD	-	Power supply
82,83		-	Non connect
84	ANA_TT	O	Analog./T.TONE
85	LEF_MIX	O	Select 1
86	LEF_OUT	O	Select 2
87	MIX_OUT	O	Select 3
88	$\overline{\text{S_MUTE}}$	O	S.MUTE
89~93		-	Non connect
94	TEST	-	Test terminal
95~100		-	Non connect

JVC

VICTOR COMPANY OF JAPAN, LIMITED
AUDIO & COMMUNICATION BUSINESS DIVISION
PERSONAL & MOBILE NETWORK BUSINESS UNIT. 10-1,1chome,Ohwatari-machi,Maebashi-city,371-8543,Japan

(No.20979)

Printed in Japan
200105(V)

Block diagrams

■ Signal I/O block section



■ Main section



■ Video section



■ Video input section



■ DSP section



■ S Video section



■ Tuner section



■ Audio input section



■ System control & FL section



Standard schematic diagrams

■ Power supply section



sheet 10/11

sheet 5/11

SHEET NUMBER	CIRCUIT DESCRIPTION
1/11	POWER SUPPLY
2/11	MAIN
3/11	AUDIO
4/11	AUDIO SIGNAL INPUT
5/11	VIDEO SIGNAL INPUT
6/11	DVD
7/11	AUDIO AMP (FRONT CHANNEL)
8/11	AUDIO AMP (CENTER, REAR CHANNEL)
9/11	DSP
10/11	SYSTEM CONTROL
11/11	TUNER

⚠ Parts are safety assurance parts. When replacing those parts make sure to use the specified one.

■ Main & Speaker terminal section



*MARK

	RX-8010			RX-9010
	J, C	B, E, EN	US, UN, UW	
RB11	15	12	12	15
DB11	MTZJ24.JC	MTZJ20.JC	MTZJ20.JB	MTZJ24.JC
CB01	0.01	0.1	0.1	0.01
CB02	0.01	0.1	0.1	0.01
CB05	0.01	0.1	0.1	0.01
CB33-CB34		USE	USE	
CB39-CB40		USE	USE	
CB45-CB48		USE	USE	
CB41-CB44		USE	USE	
RB33-RB34		USE	USE	
RB37-RB38		USE	USE	
CB35-CB38		USE	USE	
CB81		USE	USE	
CB91		USE	USE	
CB86		USE	USE	
RB85		USE	USE	
CB85		USE	USE	
CB83-CB84		USE	USE	
CB92-CB93		USE	USE	
CB89-CB90		USE	USE	
RB87-RB88		USE	USE	
CB87-CB88		USE	USE	
RY833				USE
RB35				USE
DB35				USE
CB1-CB2		USE	USE	
LB43-LB45		USE	USE	
B123-B125	USE			USE

FRONT Signal
CENTER Signal
REAR Signal

⚠ Parts are safety assurance parts. When replacing those parts make sure to use the specified one.

■ Audio section



*MARK

	RX-8010			RX-9010
	J- C	B- E- EN	US- UN- UW	
R930	USE			USE
R999	USE		USE	USE
R934		USE		
R935		USE		
R936		USE		
CN102		USE		
R917	SHORT	SHORT	USE	SHORT
R931	43	43	43	39
R932	43	43	43	39
D903				USE

■ Audio / V Audio signal input section





AUDIO Signal

TUNER Signal

PHONO Signal

VIDEO AUDIO Signal

REAR Signal

⚠ Parts are safety assurance parts. When replacing those parts make sure to use the specified one.

■ Video / S video signal input section

RX-8012RSL
#001~800



Sheet 10/11 Sheet 6/11



Sheet 10/11 Sheet 6/11

Sheet 3/11

Sheet 3/11

⚠ Parts are safety assurance parts. When replacing those parts make sure to use the specified one.

■ Video / S video signal input section

RX-8012RSL
#801~1300





⚠ Parts are safety assurance parts. When replacing those parts make sure to use the specified one.

■ DVD section



SHEET 6/11

A | B | C | 2-10 | D | E | F | G | H

■ Audio amplifier section (1/2)



sheet 2/11



sheet 2/11

*MARK

	RX-8010		RX-9010
	B, E, EN, US, UN, UW	J, C	
Q761, Q762	2SD2390/OPY/-F6	2SD2560/OPY/-F6	2SD2560/OPY/-F6
Q763, Q764	2SB1560/OPY/-F6	2SB1647/OPY/-F6	2SB1647/OPY/-F6

FRONT Signal

⚠ Parts are safety assurance parts. When replacing those parts make sure to use the specified one.

SHEET 7/11

■ Audio amplifier section (2/2)



sheet 6/11

sheet 2/11

CENTER Signal

REAR Signal

⚠ Parts are safety assurance parts. When replacing those parts make sure to use the specified one.



sheet 2/11



sheet 2/11

*MARK

	RX-8010	RX-9010
C1803- C1804	100P	180P

	J/C	EXCEPT J/C
C1703-C1805-C1806	100P	220P

■ DSP section


IC501
XCA56367PV150
IC581
uPD784215AGC152
IC571
AK4527BVQ
IC551
AK4112AVF
IC502
TC7S04FU
IC582
TC7SET32FU
IC503
TC7S04FU
IC505
PQ070XZ1HZ
IC511
W24L01DAJ-12
IC583
PQ30DZ53
LIN
RIN
SL
SR
C
SUBWFR
L
R
LIN-
LIN+
RIN+
RIN-
LOUT1
ROUT1
LOUT2
ROUT2
LOUT3
ROUT3
DIGITALOUT
DIGITAL IN2
DIGITAL IN3
DIGITAL IN4
DIGITAL IN1
AUDIO Signal
FRONT Signal
CENTER Signal
REAR Signal
LVA10223
Parts are safety assurance parts.
When replacing those parts make
sure to use the specified one.
sheet 6/11
sheet 3/11
SHEET 9/11

■ System control & FL display section

LVA10218-1

sheet 1/11

sheet 2/11

sheet 5/11 TO CN244 OF LVA10219-5

sheet 5/11 TO CN206 OF LVA10219-4

sheet 4/11 TO CN416 OF LVA10219-3

TO CN402 OF LVA10222-2

TO CN400 OF LVA10222-1

LVA10218-2

LVA10218-3

⚠ Parts are safety assurance parts. When replacing those parts make sure to use the specified one.

SHEET 10/11

■ Tuner section



FM / Tuner signal

⚠ Parts are safety assurance parts. When replacing those parts make sure to use the specified one.

SHEET 11/11

Printed circuit boards

■ Main board



■ Micon board


PW10
PW11
PW12
PW13
PW14
PW15
PW16
PW25
PW22
PW27
PW23
PW24
PW21
VS1
FC5
FC6
PW19
PW26
PW18
PW17
PW20
PW30
FC1
FC2
R1
TA1
TA2
EP1
FW91
C52
D62
D64
D61
D63
D57
RY1
PW28
PW40
PW29
C1
C66
C65
C63
C61
TH71
Q54
R67
R66
R55
B3234
B3233
B3334
CN71
Q52
R54
C55
D56
C64
C70
D71
C71
C72
D72
D74
T2
FC4
FC3
Q71
R72
R73
C73
Q74
D75
C74
B3237
B3238
C69
C68
CN402
HS51
Q51
C53
B3128
B3121
B3126
D51
D52
D53
D54
C54
C52
R53
R52
EP51
CN932
CN931
B3115
B3221
B3114
B3113
CN481
Q907
Q904
Q905
Q904
Q903
B3231
R931
R932
R933
Q931
C932
C931
B3751
B3320
B3322
B3315
B3314
B3601
R940
B3112
B3111
B3110
HS701
B3901
R941
R942
R943
Q941
C942
C941
Q921
C922
C921
R921
R922
R923
D921
R998
R996
R994
R979
R977
R997
R993
R975
B3132
B3131
R978
B3121
B3122
B3123
B3124
B3125
B3430
B3233
B3239
B3331
B3307
B3308
B3309
B3310
B3311
B3312
B3313
B3317
B3316
B3318
B3320
B3321
B3322
B3323
B3324
B3325
B3326
B3327
B3328
B3329
B3330
B3331
B3332
B3333
B3335
B3336
B3337
B3338
B3339
B3340
B3341
B3342
B3343
B3344
B3345
B3346
B3347
B3348
B3349
B3350
B3351
B3352
B3353
B3354
B3355
B3356
B3357
B3358
B3359
B3360
B3361
B3362
B3363
B3364
B3365
B3366
B3367
B3368
B3369
B3370
B3371
B3372
B3373
B3374

■ Front board


CN412
D4600
CN482
D491
D490
S491
S490
R491
R490
CN480
D480
S480
S481
S482
S483
R480
R481
R482
R483

■ **Input board** (Reverse side)

RX-8012RSL
#001~800



■ **Input board** (Forward side)

RX-8012RSL
#001~800



■ **Input board** (Reverse side)

RX-8012RSL
#801~1300



■ **Input board** (Forward side)

RX-8012RSL
#801~1300



■ Power board



■ DSP board

Reverse side



Forward side



■ Tuner board


AT101
Q112
Q113
Q103
Q111
Q121
[DOM]
B173
B176
B177
B198
B197
B194
B192
B195
B189
B193
B134
B135
B151
B122
B121
B188
B133
B123
B199
B174
B175
B178
B105
D124
D125
B172
B191
B190
B102
B106
B113
B112
B111
C107
C101
C102
C111
C112
C113
C117
C118
C158
C157
C168
C133
C136
C135
C161
C162
C137
C130
C186
C149
C148
C147
C146
C184
C185
C128
C129
C126
C121
C122
C123
C130
C195
C196
C193
C191
C192
C194
C197
R115
R112
R104
R105
R107
R108
R109
R111
R119
R129
R103
R133
R132
R122
R124
R126
R143
R142
R150
R147
R146
R140
R157
R156
R162
R161
R141
R145
R144
R158
R159
R160
R163
R164
R127
R134
R130
R128
R194
R193
R191
X121
X191
CF102
CF101
CF150
CF103
IC121
IC191
IL42
RF101
CN111
CN112
D128
D127
D122
D123
D131
D129
L112
L111
T2D

PARTS LIST

[RX-8010RBK]
[RX-8012RSL]

* All printed circuit boards and its assemblies are not available as service parts.

Area suffix

E ---------- Continental Europe
EN ---------- Northern Europe

- Contents -

Exploded view of general assembly and parts list ---------- 3- 3
Electrical parts list ---------- 3- 5
Packing materials and accessories parts list ---------- 3-23

< MEMO >

Exploded view of general assembly and parts list

Block No. M 1 M M



■ Parts list (General assembly)

Block No. M1MM

⚠	Item	Parts number	Parts name	Q'ty	Description	Area
	1	LV10469-003A	FRONT PANEL	1	RX-8010RBK	
		LV10469-008A	FRONT PANEL	1	RX-8012RSL	
	2	VJD5429-002SS	JVC MARK	1	RX-8012RSL	
		VJD5429-001SS	JVC MARK	1	RX-8010RBK	
	3	LV20950-006A	LENS	1		
	4	LV10470-002A	SUB PANEL	1	RX-8012RSL	
		LV10470-001A	SUB PANEL	1	RX-8010RBK	
	5	LV20939-002A	PUSH BUTTON	1	RX-8012RSL	
		LV20939-003A	PUSH BUTTON	1	RX-8010RBK	
	6	LV42096-001A	INDICATOR	1	POWER	
	7	LV20951-001A	PUSH BUTTON	1	TUNER	
	8	LV20940-001A	P.BUTTON ASSY	1	RX-8010RBK	
		LV20940-002A	P.BUTTON ASSY	1	RX-8012RSL	
	9	LV20944-001A	P.BUTTON ASSY	1	RX-8010RBK	
		LV20944-002A	P.BUTTON ASSY	1	RX-8012RSL	
	10	LV20942-001A	PUSH BUTTON	1	RX-8010RBK	
		LV20942-002A	PUSH BUTTON	1	RX-8012RSL	
	11	LV32486-002A	PUSH BUTTON	1	RX-8012RSL	
		LV32486-001A	P.BUTTON ASSY	1	RX-8010RBK	
	12	LV42095-002A	FL SCREEN	1	FL	
	13	QYSBSF2610Z	SCREW	2	FRONT C.B	
	14	QYSBSF2610Z	SCREW	2	FRONT C.B	
	15	QYSBSF2610Z	SCREW	8	FRONT C.B FL	
	16	QUQ412-0815CJ	FFC WIRE	1		
	17	QUQ412-1030CJ	FFC WIRE	1		
	18	QYSDSG3006Z	SCREW	4	FRONT D	
	19	QYSBSG3006Z	T.SCREW	3	FRONT U	
	20	LV10019-003A	CHASSIS BASE	1		
	21	EXO150010H09S11	FELT SPACER	1	FOR C.BASE	
	22	LV10471-002A	FRONT BRACKET	1		
	23	QYSDSG3006Z	SCREW	7	C.B-F.B	
	24	LV42094-002A	H.P. BKT	1		
	25	QYSBSG3006Z	T.SCREW	1	H.P BKT-F.B	
	26	VKZ4150-001	SPECIAL NUT	1		
	27	E68587-223SM	CB BKT	3		
	28	QYSBST3006Z	T.SCREW	3	C.B-BKT	
	29	QZF6018-003	FOOT	4	RX-8012RSL	
		QZF6018-001	FOOT	4	RX-8010RBK	
	31	QYSBST3010Z	T.SCREW	4	FOOT	
	32	LV20984-002A	HEAT SINK	1		
	33	E73525-003SS	SCREW	10	TR	
	34	LV42098-001A	C.B BKT	1	PRI/SEC C.B	
	35	QYSBST3006Z	T.SCREW	1	C.B BKT	
	36	LV32433-001A	H.S BRACKET(R)	1		
	37	LV32434-001A	H.S BRACKET(L)	1		
	38	QYSBSG3008Z	T.SCREW	4	H.S-BKT	
	39	QYSBSG3006Z	T.SCREW	2	H.S BKT-F.BKT	
	40	QYSBSG3006Z	T.SCREW	2	H.S BKT	

■ Parts list (General assembly)

Block No. M1MM

⚠	Item	Parts number	Parts name	Q'ty	Description	Area
	41	QYSBST3006Z	T.SCREW	4	H.S BKT-CHASSIS	
	42	QYSBSG3006Z	T.SCREW	2	M.C.B	
	43	E65923-003	TAPPING SCREW	1	M.C.B	
	44	LV30225-0B2A	SPACER	1		
	45	QYSBSG3006Z	T.SCREW	3	H.S-C.B	
	46	QYSBSG3006Z	T.SCREW	3	P.C.B-CHASSIS	
	47	QYSBSG3006Z	T.SCREW	1	C.B-CHASSIS	
⚠	48	QQT0325-002	POWER TRANSF	1	MATSUSHITA	
	49	QYSDSTL4008Z	SPECIAL SCREW	4	P.TRANS	
	50	LV10472-014A	REAR PANEL	1	RX-8012RSL	
		LV10472-013A	REAR PANEL	1	RX-8010RBK	
	51	QYSBSGY3008M	SPECIAL SCREW	3	R.P-C.BASE	
	52	QYSBSGY3008M	SPECIAL SCREW	1	R.P-ud---	
	53	QYSBSGY3008M	SPECIAL SCREW	2	TUNER	
	54	FMYH4004-001	PLASTIC RIVET	1	A.INPUT	
	55	QYSBSGY3008M	SPECIAL SCREW	4	A.INPUT	
	56	QYSBSGY3008M	SPECIAL SCREW	3	V.INPUT	
	57	QYSBSGY3008M	SPECIAL SCREW	3	VIDEO	
	58	QYSBSGY3008M	SPECIAL SCREW	4	S VIDEO	
	59	QYSBSGY3008M	SPECIAL SCREW	6	DIGITAL	
	60	QYSBSGY3008M	SPECIAL SCREW	4	COMPONENT	
	61	QYSBSGY3008M	SPECIAL SCREW	4	SPK C.B	
	62	E409257-001	GND TERMINAL	1		
⚠	63	QMPK150-200-JD	POWER CORD	1		
⚠	64	QZW0033-001	STRAIN RELIEF	1		
	65	LV20038-009A/S/	TOP COVER	1	RX-8010RBK	
		LV20038-010A/S/	TOP COVER	1	RX-8012RSL	
	66	QYSBSGY3008M	SPECIAL SCREW	3		
	67	E406308-004	SPECIAL SCREW	4	RX-8012RSL	
		E406308-003	SPECIAL SCREW	4	RX-8010RBK	
	68	LV32435-003A	VOL KNOB	1	RX-8010RBK	
		LV32435-004A	VOL KNOB	1	RX-8012RSL	
⚠	69	QMF51E2-3R15-J1	FUSE	1	F1	
⚠	70	QMF51E2-2R0-J1	FUSE	2	F61, F62	
	72	E409396-002	CAUTION LABEL	1		
	73	E3400-444	FELT SPACER	2	FS400, FS401	
	74	QYSBSG3008E	T.SCREW	3		
	75	QYSBSG3008E	T.SCREW	3		
	76	LV20952-001A	PUSH BUTTON	1	RDS/M.ROOM	
	77	QYSBSG3006Z	T.SCREW	1		
	78	LV30077-004A	PROTECT SHEET	1	RX-8010RBK	
		LV30077-006A	PROTECT SHEET	1	RX-8012RSL	
	79	LV32488-004A	JACK COVER	1	RX-8012RSL	
		LV32488-003A	JACK COVER	1	RX-8010RBK	
⚠	80	QMF51E2-R10-J1	FUSE	1	F2	
	81	E307572-001	FASTENER	1		

■ **Electrical parts list (Main board)** **Block No. 01**

⚠	Item	Parts number	Parts name	Remarks	Area
	C 801	QFN82CK-104	M CAPACITOR	.10MF 10% 160V	
	C 802	QFN82CK-104	M CAPACITOR	.10MF 10% 160V	
	C 805	QFN82CK-104	M CAPACITOR	.10MF 10% 160V	
	C 807	QEZ0462-688	E CAPACITOR	6800MF	
	C 808	QEZ0462-688	E CAPACITOR	6800MF	
	C 811	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 816	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	C 823	QETN1CM-476Z	E CAPACITOR	47MF 20% 16V	
	C 824	QETN1EM-106Z	E CAPACITOR	10MF 20% 25V	
	C 833	QDVB1EZ-223Y	C CAPACITOR		
	C 834	QDVB1EZ-223Y	C CAPACITOR		
	C 835	QFLC1HJ-223Z	M CAPACITOR	.022MF 5% 50V	
	C 836	QFLC1HJ-223Z	M CAPACITOR	.022MF 5% 50V	
	C 837	QFLC1HJ-223Z	M CAPACITOR	.022MF 5% 50V	
	C 838	QFLC1HJ-223Z	M CAPACITOR	.022MF 5% 50V	
	C 839	QDVB1EZ-223Y	C CAPACITOR		
	C 840	QDVB1EZ-223Y	C CAPACITOR		
	C 841	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C 842	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C 843	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C 844	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C 845	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C 846	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C 847	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C 848	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C 850	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 851	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 852	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 853	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 881	QCBB1HK-221Y	C CAPACITOR	220PF 10% 50V	
	C 883	QCBB1HK-221Y	C CAPACITOR	220PF 10% 50V	
	C 884	QCBB1HK-221Y	C CAPACITOR	220PF 10% 50V	
	C 885	QFVJ1HJ-104Z	MF CAPACITOR	.10MF 5% 50V	
	C 886	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C 887	QFVJ1HJ-104Z	MF CAPACITOR	.10MF 5% 50V	
	C 888	QFVJ1HJ-104Z	MF CAPACITOR	.10MF 5% 50V	
	C 889	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C 890	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C 891	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C 892	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C 893	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	CN 72	QGB2510K1-11	CONNECTOR		
	CN 82	QGB2510K1-09	CONNECTOR		
	CN701	QGB2510J1-14	CONNECTOR		
	CN702	QGB2510J1-14	CONNECTOR		
	CN703	QGB2510J1-10	CONNECTOR		
	CN705	QGB2510J1-12	CONNECTOR		
	CN706	QGB2510J1-12	CONNECTOR		
	CN721	QGA2501C1-03	3P CONNECTOR		
	CN723	QGA2501C1-04	4P CONNECTOR		
	CN801	QJK012-032403	SKT WIRE ASSY		
	CN813	QGA3901C1-04	4P CONNECTOR		
	CN814	QGA3901C1-06	6P PLUG ASSY		
⚠	CN823	QJK015-043004	SKT WIRE ASSY		
⚠	CN824	QJK015-063504	SKT WIRE ASSY		
	CN831	QGD2501C1-04Z	SOCKET		
	CN881	QGD2501C1-03Z	SOCKET		
⚠	D 801	30DF2-FC	DIODE		
⚠	D 802	30DF2-FC	DIODE		
⚠	D 803	30DF2-FC	DIODE		
⚠	D 804	30DF2-FC	DIODE		
	D 811	MTZJ22C-T2	Z DIODE		
	D 816	MTZJ18C-T2	Z DIODE		

⚠	Item	Parts number	Parts name	Remarks	Area
	D 825	1SS133-T2	SI DIODE		
	D 831	1SS133-T2	SI DIODE		
	D 832	1SS133-T2	SI DIODE		
	D 841	MTZJ5.1C-T2	Z DIODE		
	D 842	1SS133-T2	SI DIODE		
	D 843	1SS133-T2	SI DIODE		
	D 844	1SS133-T2	SI DIODE		
	D 845	1SS133-T2	SI DIODE		
	D 846	1SS133-T2	SI DIODE		
	D 851	1SS133-T2	SI DIODE		
	D 852	1SS133-T2	SI DIODE		
	D 871	1SS133-T2	SI DIODE		
	EP801	QNZ0136-001Z	EARTH PLATE		
	FW931	QUM137-08DGZ4	PARA RIBON WIRE		
⚠	L 843	QQLZ005-R45	INDUCTOR		
⚠	L 844	QQLZ005-R45	INDUCTOR		
⚠	L 845	QQLZ005-R45	INDUCTOR		
	O 811	2SD2395/EF/	TRANSISTOR		
	O 812	KTC3200/GL/-T	TRANSISTOR		
	O 823	KTC3199/GL/-T	TRANSISTOR		
	O 824	KTC3200/GL/-T	TRANSISTOR		
	O 825	KTA1268/GL/-T	TRANSISTOR		
	O 830	KRC109M-T	D TRANSISTOR		
	O 831	KRC109M-T	D TRANSISTOR		
	O 832	KRC109M-T	D TRANSISTOR		
	O 833	KRC109M-T	D TRANSISTOR		
	O 834	KRC109M-T	D TRANSISTOR		
	O 835	KRC109M-T	D TRANSISTOR		
	O 836	KRC109M-T	D TRANSISTOR		
	R 801	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 802	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 811	QRJ146J-120X	UNF C RESISTOR	12 5% 1/4W	
	R 812	QRK126J-332X	UNF C RESISTOR	3.3K 5% 1/2W	
	R 813	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	R 814	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 815	QRJ146J-120X	UNF C RESISTOR	12 5% 1/4W	
	R 816	QRL022J-332	UNF OMF RESISTOR	3.3K 5% 1/2W	
	R 823	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 824	QRE141J-134Y	C RESISTOR	130K 5% 1/4W	
	R 825	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 826	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 831	QRJ146J-120X	UNF C RESISTOR	12 5% 1/4W	
	R 832	QRJ146J-120X	UNF C RESISTOR	12 5% 1/4W	
	R 833	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R 834	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R 837	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R 838	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R 841	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 842	QRE141J-823Y	C RESISTOR	82K 5% 1/4W	
	R 843	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 844	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 845	QRE141J-823Y	C RESISTOR	82K 5% 1/4W	
	R 851	QRJ146J-120X	UNF C RESISTOR	12 5% 1/4W	
	R 852	QRJ146J-120X	UNF C RESISTOR	12 5% 1/4W	
	R 855	QRJ146J-392X	UNF C RESISTOR	3.9K 5% 1/4W	
	R 856	QRE141J-223Y	C RESISTOR	22K 5% 1/4W	
	R 857	QRE141J-682Y	C RESISTOR	6.8K 5% 1/4W	
	R 858	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 859	QRE141J-223Y	C RESISTOR	22K 5% 1/4W	
	R 860	QRE141J-682Y	C RESISTOR	6.8K 5% 1/4W	
	R 861	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 862	QRE141J-223Y	C RESISTOR	22K 5% 1/4W	
	R 863	QRE141J-682Y	C RESISTOR	6.8K 5% 1/4W	

■ **Electrical parts list (Main board)** **Block No. 01**

⚠	Item	Parts number	Parts name	Remarks	Area
	R 864	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 865	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 866	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 867	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 871	QRJ146J-120X	UNF C RESISTOR	12 5% 1/4W	
	R 885	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R 887	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R 888	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	RY831	QSK0109-001	RELAY		
	RY832	QSK0109-001	RELAY		
	RY851	QSK0109-001	RELAY		
	RY852	QSK0109-001	RELAY		
	RY871	QSK0109-001	RELAY		
	ST831	QNB0111-001	SPK TERMINAL		
	ST851	QNB0079-001	SPK TERMINAL		

■ **Electrical parts list (Front board)** **Block No. 02**

⚠	Item	Parts number	Parts name	Remarks	Area
	BK400	LV42092-001A	FL HOLDER(R)		
	BK401	LV42093-001A	FL HOLDER(L)		
	C 400	QEKC1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 401	NCB31CK-104X	C CAPACITOR		
	C 402	NCB31CK-104X	C CAPACITOR		
	C 404	NCB31EK-223X	C CAPACITOR		
	C 406	NCB31HK-331X	C CAPACITOR		
	C 407	QCZ0205-155Z	ML C CAPACITOR	1.5MF	
	C 408	NCB31EK-223X	C CAPACITOR		
	C 409	QEKC1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 410	QEKC1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 411	NCB21AK-225X	C CAPACITOR		
	C 412	QEKC0JM-107Z	E CAPACITOR	100MF 20% 6.3V	
	C 420	NCB31HK-471X	C CAPACITOR		
	C 421	NCB31HK-471X	C CAPACITOR		
	C 422	NCB31HK-471X	C CAPACITOR		
	C 423	NCB31HK-471X	C CAPACITOR		
	C 424	NCB31HK-471X	C CAPACITOR		
	C 425	NCB31HK-471X	C CAPACITOR		
	C 430	NCB31CK-104X	C CAPACITOR		
	C 431	NCB31EK-223X	C CAPACITOR		
	C 432	NCS31HJ-220X	C CAPACITOR		
	C 433	NCS31HJ-220X	C CAPACITOR		
	C 435	NCB31EK-104X	C CAPACITOR		
	C 436	NCB31EK-104X	C CAPACITOR		
	C 437	NCB31EK-104X	C CAPACITOR		
	C 438	NCB31EK-104X	C CAPACITOR		
	C 439	NCB31EK-104X	C CAPACITOR		
	C 440	NCB31EK-104X	C CAPACITOR		
	C 441	QEKC1CM-106Z	E CAPACITOR	10MF 20% 16V	
	C 442	QETN1AM-107Z	E CAPACITOR	100MF 20% 10V	
	C 443	QETN1AM-107Z	E CAPACITOR	100MF 20% 10V	
⚠	C 444	NCS31HJ-331X	C CAPACITOR		
⚠	C 448	QCFB1HZ-104Y	C CAPACITOR	.10MF +80:-20%	
	C 456	NCB31EK-104X	C CAPACITOR		
	C 460	NCB31CK-104X	C CAPACITOR		
	C 461	NCB31HK-221X	C CAPACITOR	(FTZ)	
	C 462	NCB31HK-221X	C CAPACITOR	(FTZ)	
	C 463	NCS31HJ-470X	C CAPACITOR		
	C 464	NCS31HJ-470X	C CAPACITOR		
	C 465	NCS31HJ-470X	C CAPACITOR		
	CN406	WJP0031-001A	C-B WIRE ASSY		
	CN410	QGF1205F1-10	CONNECTOR		
	CN412	QGF1205F1-08	CONNECTOR		
	CN420	QJK025-031301	C-B WIRE ASSY	(LEFT)	
	CN422	QJK025-041201	SIN ID C-B WIRE	(RIGHT)	
	CN430	QGA2501C1-03	3P CONNECTOR		
	CN432	QGA2501C1-04	4P CONNECTOR		
	D 410	SLR-342VC-T	LED	(FM/AM)	
	D 411	SLR-342VC-T	LED	(USB)	
	D 412	SLR-342VC-T	LED	(TAPE)	
	D 413	SLR-342VC-T	LED	(CDR)	
	D 414	SLR-342VC-T	LED	(PHONE)	
	D 415	SLR-342VC-T	LED	(CD)	
	D 416	SLR-342VC-T	LED	(TV/DBS)	
	D 417	SLR-342VC-T	LED	(VIDEO)	
	D 418	SLR-342VC-T	LED	(VCR2)	
	D 419	SLR-342VC-T	LED	(VCR1)	
	D 420	SLR-342VC-T	LED	(DVD MULTI)	
	D 421	SLR-342VC-T	LED	(DVD)	
	D 422	SLR-342VC-T	LED	(SURROUND)	
	D 423	SLR-342VC-T	LED	(DSP)	
	D 480	SLR-342VC-T	LED	(STANDBY)	

⚠	Item	Parts number	Parts name	Remarks	Area
	D 490	SLR-342VC-T	LED	(DIRECT)	
	D 491	SLR-342VC-T	LED	(BASS)	
	DI400	QLF0084-001	FL TUBE		
	IC400	MN101C35DHL1	IC		
	IC402	BU2092	IC		
	IC404	GP1U281X	IC		
	IC410	PCM2702E-X	IC		
	IC411	NJU7241F33-X	IC		
	J 400	QND0026-001	S JACK		
	J 401	QNZ0541-001	USB JACK		
	JS400	QSW0898-001	JOG VOLUME		
⚠	K 451	NQR0201-018X	INDUCTOR		
⚠	K 452	NQR0201-018X	INDUCTOR		
⚠	K 453	NQR0201-018X	INDUCTOR		
⚠	K 454	NQR0201-018X	INDUCTOR		
⚠	K 455	NQR0201-018X	INDUCTOR		
	K 456	NRSA63J-0R0X	MG RESISTOR		
	O 402	DTC114TKA-X	TRANSISTOR		
	O 403	DTC144WKA-X	TRANSISTOR		
	O 407	DTC114YKA-X	CHIP D TRANSIST		
	O 408	DTC114YKA-X	CHIP D TRANSIST		
	O 410	DTA114YKA-X	TRANSISTOR	(DIRECT)	
	O 411	DTA114YKA-X	TRANSISTOR	(BASS)	
	O 412	DTA114YKA-X	TRANSISTOR	(STANBY)	
	O 413	DTA114YKA-X	TRANSISTOR	(SURROUND)	
	O 414	DTA114YKA-X	TRANSISTOR	(DSP)	
	R 400	NRSA63J-102X	MG RESISTOR		
	R 401	NRSA63J-102X	MG RESISTOR		
	R 402	NRSA63J-122X	MG RESISTOR		
	R 403	NRSA63J-102X	MG RESISTOR		
	R 404	NRSA63J-102X	MG RESISTOR		
	R 405	NRSA63J-122X	MG RESISTOR		
	R 406	NRSA63J-152X	MG RESISTOR		
	R 407	NRSA63J-222X	MG RESISTOR		
	R 408	NRSA63J-272X	MG RESISTOR		
	R 409	NRSA63J-392X	MG RESISTOR		
	R 410	NRSA63J-102X	MG RESISTOR		
	R 411	NRSA63J-102X	MG RESISTOR		
	R 412	NRSA63J-122X	MG RESISTOR		
	R 413	NRSA63J-152X	MG RESISTOR		
	R 414	NRSA63J-222X	MG RESISTOR		
	R 415	NRSA63J-272X	MG RESISTOR		
	R 416	NRSA63J-392X	MG RESISTOR		
	R 417	NRSA63J-102X	MG RESISTOR		
	R 418	NRSA63J-102X	MG RESISTOR		
	R 419	NRSA63J-122X	MG RESISTOR		
	R 420	NRSA63J-152X	MG RESISTOR		
	R 421	NRSA63J-222X	MG RESISTOR		
	R 422	NRSA63J-272X	MG RESISTOR		
	R 423	NRSA63J-392X	MG RESISTOR		
	R 424	NRSA63J-102X	MG RESISTOR		
	R 425	NRSA63J-102X	MG RESISTOR		
	R 426	NRSA63J-122X	MG RESISTOR		
	R 431	NRSA63J-102X	MG RESISTOR		
	R 432	NRSA63J-102X	MG RESISTOR		
	R 433	NRSA63J-122X	MG RESISTOR		
	R 434	NRSA63J-152X	MG RESISTOR		
	R 435	NRSA63J-222X	MG RESISTOR		
	R 436	NRSA63J-102X	MG RESISTOR		
	R 437	NRSA63J-102X	MG RESISTOR		
	R 438	NRSA63J-122X	MG RESISTOR		
	R 443	NRSA63J-102X	MG RESISTOR		
	R 444	NRSA63J-102X	MG RESISTOR		

■ **Electrical parts list (Front board)** **Block No. 02**

⚠	Item	Parts number	Parts name	Remarks	Area
	R 445	NRSA63J-103X	MG RESISTOR		
	R 446	NRSA63J-103X	MG RESISTOR		
	R 447	NRSA63J-103X	MG RESISTOR		
	R 448	NRSA63J-103X	MG RESISTOR		
	R 449	NRSA63J-103X	MG RESISTOR		
	R 450	NRSA63J-103X	MG RESISTOR		
	R 451	NRSA63J-103X	MG RESISTOR		
	R 452	NRSA63J-103X	MG RESISTOR		
	R 453	NRSA63J-103X	MG RESISTOR		
	R 454	NRSA63J-103X	MG RESISTOR		
	R 455	NRSA63J-471X	MG RESISTOR		
	R 456	NRSA63J-103X	MG RESISTOR		
	R 457	NRSA63J-103X	MG RESISTOR		
	R 458	NRSA63J-103X	MG RESISTOR		
	R 459	NRSA63J-221X	MG RESISTOR		
	R 460	NRSA63J-221X	MG RESISTOR		
	R 461	NRSA63J-221X	MG RESISTOR		
	R 462	NRSA63J-221X	MG RESISTOR		
	R 463	NRSA63J-221X	MG RESISTOR		
	R 464	NRSA63J-221X	MG RESISTOR		
	R 465	NRSA63J-331X	MG RESISTOR		
	R 466	NRSA63J-331X	MG RESISTOR		
	R 467	NRSA63J-221X	MG RESISTOR		
	R 468	NRSA63J-221X	MG RESISTOR		
	R 469	NRSA63J-221X	MG RESISTOR		
	R 470	NRSA63J-750X	MG RESISTOR		
	R 471	NRSA63J-750X	MG RESISTOR		
	R 472	NRSA63J-750X	MG RESISTOR		
	R 473	NRSA63J-152X	MG RESISTOR		
	R 474	NRSA63J-105X	MG RESISTOR		
	R 475	NRSA63J-220X	MG RESISTOR		
	R 476	NRSA63J-220X	MG RESISTOR		
	R 477	NRSA63J-0R0X	MG RESISTOR		
	R 479	NRSA63J-181X	MG RESISTOR		
	R 480	NRSA63J-152X	MG RESISTOR		
	R 481	NRSA63J-222X	MG RESISTOR		
	R 482	NRSA63J-272X	MG RESISTOR		
	R 483	NRSA63J-392X	MG RESISTOR		
	R 490	NRSA63J-272X	MG RESISTOR		
	R 491	NRSA63J-392X	MG RESISTOR		
	R 495	NRSA63J-102X	MG RESISTOR		
	S 400	QSW0683-001Z	PUSH SWITCH	(SURROUND)	
	S 401	QSW0683-001Z	PUSH SWITCH	(DSP MODE)	
	S 402	QSW0683-001Z	PUSH SWITCH	(INPUT MODE)	
	S 403	QSW0683-001Z	PUSH SWITCH	(TUNING UP)	
	S 404	QSW0683-001Z	PUSH SWITCH	(PRESET UP)	
	S 405	QSW0683-001Z	PUSH SWITCH	(FM MODE)	
	S 406	QSW0683-001Z	PUSH SWITCH	(MEMORY)	
	S 407	QSW0683-001Z	PUSH SWITCH	(MIDNIGHT MODE)	
	S 408	QSW0683-001Z	PUSH SWITCH	(DVD)	
	S 409	QSW0683-001Z	PUSH SWITCH	(DVD MULTI)	
	S 410	QSW0683-001Z	PUSH SWITCH	(TUNING DOWN)	
	S 411	QSW0683-001Z	PUSH SWITCH	(PRESET DOWN)	
	S 412	QSW0683-001Z	PUSH SWITCH	(VCR1)	
	S 413	QSW0683-001Z	PUSH SWITCH	(VCR2)	
	S 414	QSW0683-001Z	PUSH SWITCH	(VIDEO)	
	S 415	QSW0683-001Z	PUSH SWITCH	(CD)	
	S 416	QSW0683-001Z	PUSH SWITCH	(TV/DBS)	
	S 417	QSW0683-001Z	PUSH SWITCH	(CDR)	
	S 418	QSW0683-001Z	PUSH SWITCH	(USB AUDIO)	
	S 419	QSW0683-001Z	PUSH SWITCH	(PHONE)	
	S 420	QSW0683-001Z	PUSH SWITCH	(FM/AM)	
	S 421	QSW0683-001Z	PUSH SWITCH	(DIGITAL SEA)	
	S 422	QSW0683-001Z	PUSH SWITCH	(LEVEL ADJUST)	
	S 423	QSW0683-001Z	PUSH SWITCH	(TAPE/MD)	
	S 424	QSW0683-001Z	PUSH SWITCH	(DOWN)	
	S 425	QSW0683-001Z	PUSH SWITCH	(EFECT)	
	S 426	QSW0683-001Z	PUSH SWITCH	(SETTING)	
	S 427	QSW0683-001Z	PUSH SWITCH	(MAIN/EON)	
	S 428	QSW0683-001Z	PUSH SWITCH	(SUB/PTY)	
	S 429	QSW0683-001Z	PUSH SWITCH	(SUB CTL/TA)	
	S 430	QSW0683-001Z	PUSH SWITCH	(DIMMER/DISP)	
	S 431	QSW0683-001Z	PUSH SWITCH	(UP)	
	S 480	QSW0683-001Z	PUSH SWITCH	(POWER)	
	S 481	QSW0683-001Z	PUSH SWITCH	(SPK1)	
	S 482	QSW0683-001Z	PUSH SWITCH	(SPK2)	
	S 483	QSW0683-001Z	PUSH SWITCH	(SUBWFR)	
	S 490	QSW0683-001Z	PUSH SWITCH	(DIRECT)	
	S 491	QSW0683-001Z	PUSH SWITCH	(BASS)	
	X 400	QAX0246-001Z	RESONATOR		
	X 410	QAX0320-001Z	CRYSTAL		

■ **Electrical parts list (Power board)** **Block No. 03**

⚠	Item	Parts number	Parts name	Remarks	Area
	C 701	QTE1V06-106Z	E CAPACITOR		
	C 702	QTE1V06-106Z	E CAPACITOR		
	C 703	QCS31HJ-101Z	C CAPACITOR	100PF 5% 50V	
	C 704	QCS31HJ-101Z	C CAPACITOR	100PF 5% 50V	
	C 705	QCS31HJ-101Z	C CAPACITOR	100PF 5% 50V	
	C 706	QCS31HJ-101Z	C CAPACITOR	100PF 5% 50V	
	C 707	QETN1CM-107Z	E CAPACITOR	100MF 20% 16V	
	C 708	QETN1CM-107Z	E CAPACITOR	100MF 20% 16V	
	C 709	QCS31HJ-100Z	C CAPACITOR	10PF 5% 50V	
	C 710	QCS31HJ-100Z	C CAPACITOR	10PF 5% 50V	
	C 711	QFLC1HJ-103Z	M CAPACITOR	.010MF 5% 50V	
	C 712	QFLC1HJ-103Z	M CAPACITOR	.010MF 5% 50V	
	C 713	QCS31HJ-680Z	C CAPACITOR	68PF 5% 50V	
	C 714	QCS31HJ-680Z	C CAPACITOR	68PF 5% 50V	
	C 715	QCS31HJ-680Z	C CAPACITOR	68PF 5% 50V	
	C 716	QCS31HJ-680Z	C CAPACITOR	68PF 5% 50V	
	C 717	QCS32HJ-220Z	C CAPACITOR	22PF 5% 500V	
	C 718	QCS32HJ-220Z	C CAPACITOR	22PF 5% 500V	
	C 719	QFLC1HJ-472Z	M CAPACITOR	4700PF 5% 50V	
	C 720	QFLC1HJ-472Z	M CAPACITOR	4700PF 5% 50V	
	C 741	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C 742	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C 745	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C 746	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C 751	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C 752	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C 753	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C 754	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C 791	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C 792	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C 793	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C 794	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C 795	QCF31HZ-223Z	C CAPACITOR	.022MF +80:-20%	
	C 796	QCF31HZ-223Z	C CAPACITOR	.022MF +80:-20%	
	CN711	QGB2510K1-14	CONNECTOR		
	CN712	QGB2510K1-14	CONNECTOR		
	CN713	QGB2510K1-10	CONNECTOR		
	CN715	QGB2510K1-12	CONNECTOR		
	CN716	QGB2510K1-12	CONNECTOR		
	CN722	QGA2501F1-02	CONNECTOR		
	C1701	QETN1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C1702	QCS31HJ-101Z	C CAPACITOR	100PF 5% 50V	
	C1703	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C1704	QETN1CM-107Z	E CAPACITOR	100MF 20% 16V	
	C1705	QCS31HJ-5R0Z	C CAPACITOR	5.0PF 5% 50V	
	C1711	QCS32HJ-330Z	C CAPACITOR	33PF 5% 500V	
	C1712	QFLC1HJ-103Z	M CAPACITOR	.010MF 5% 50V	
	C1713	QETN1CM-107Z	E CAPACITOR	100MF 20% 16V	
	C1715	QETN1HM-476Z	E CAPACITOR	47MF 20% 50V	
	C1741	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C1743	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C1751	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C1752	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C1761	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C1762	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C1791	QCF31HZ-223Z	C CAPACITOR	.022MF +80:-20%	
	C1801	QETN1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C1802	QETN1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C1803	QCS31HJ-101Z	C CAPACITOR	100PF 5% 50V	
	C1804	QCS31HJ-101Z	C CAPACITOR	100PF 5% 50V	
	C1805	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C1806	QCS31HJ-221Z	C CAPACITOR	220PF 5% 50V	
	C1807	QETN1CM-107Z	E CAPACITOR	100MF 20% 16V	

⚠	Item	Parts number	Parts name	Remarks	Area
	C1808	QETN1CM-107Z	E CAPACITOR	100MF 20% 16V	
	C1809	QCS31HJ-5R0Z	C CAPACITOR	5.0PF 5% 50V	
	C1810	QCS31HJ-5R0Z	C CAPACITOR	5.0PF 5% 50V	
	C1811	QCS32HJ-330Z	C CAPACITOR	33PF 5% 500V	
	C1812	QCS32HJ-330Z	C CAPACITOR	33PF 5% 500V	
	C1813	QFLC1HJ-103Z	M CAPACITOR	.010MF 5% 50V	
	C1814	QFLC1HJ-103Z	M CAPACITOR	.010MF 5% 50V	
	C1815	QETN1CM-107Z	E CAPACITOR	100MF 20% 16V	
	C1816	QETN1CM-107Z	E CAPACITOR	100MF 20% 16V	
	C1817	QETN1HM-476Z	E CAPACITOR	47MF 20% 50V	
	C1818	QETN1HM-476Z	E CAPACITOR	47MF 20% 50V	
	C1841	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C1842	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C1843	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C1844	QETN2AM-476Z	E CAPACITOR	47MF 20% 100V	
	C1851	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C1852	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C1853	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C1854	QCS32HJ-470Z	C CAPACITOR	47PF 5% 500V	
	C1861	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C1862	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C1863	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C1864	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C1891	QCF31HZ-223Z	C CAPACITOR	.022MF +80:-20%	
	C1892	QCF31HZ-223Z	C CAPACITOR	.022MF +80:-20%	
	D 701	1SS133-T2	SI DIODE		
	D 702	1SS133-T2	SI DIODE		
	D 703	1SS133-T2	SI DIODE		
	D 704	1SS133-T2	SI DIODE		
	D 771	1SS133-T2	SI DIODE		
	D 772	1SS133-T2	SI DIODE		
	D 773	1SS133-T2	SI DIODE		
	D 774	1SS133-T2	SI DIODE		
	D 791	1SS133-T2	SI DIODE		
	D 792	1SS133-T2	SI DIODE		
	D1701	1SS133-T2	SI DIODE		
	D1771	1SS133-T2	SI DIODE		
	D1772	1SS133-T2	SI DIODE		
	D1791	1SS133-T2	SI DIODE		
	D1801	1SS133-T2	SI DIODE		
	D1802	1SS133-T2	SI DIODE		
	D1871	1SS133-T2	SI DIODE		
	D1872	1SS133-T2	SI DIODE		
	D1873	1SS133-T2	SI DIODE		
	D1874	1SS133-T2	SI DIODE		
	D1891	1SS133-T2	SI DIODE		
	D1892	1SS133-T2	SI DIODE		
	L 791	QQLZ003-1R0	INDUCTOR		
	L 792	QQLZ003-1R0	INDUCTOR		
	L1761	QQLZ005-R45	INDUCTOR		
	L1861	QQLZ005-R45	INDUCTOR		
	L1862	QQLZ005-R45	INDUCTOR		
	O 701	2SC2240-BL/AB/T	TRANSISTOR		
	O 702	2SC2240-BL/AB/T	TRANSISTOR		
	O 703	2SC2240-BL/AB/T	TRANSISTOR		
	O 704	2SC2240-BL/AB/T	TRANSISTOR		
	O 705	KTA1268/GL/-T	TRANSISTOR		
	O 706	KTA1268/GL/-T	TRANSISTOR		
	O 707	KTA1268/GL/-T	TRANSISTOR		
	O 708	KTA1268/GL/-T	TRANSISTOR		
	O 709	KTA1268/GL/-T	TRANSISTOR		
	O 710	KTA1268/GL/-T	TRANSISTOR		
	O 711	KTC3200/GL/-T	TRANSISTOR		

■ **Electrical parts list (Power board)** **Block No. 03**

⚠	Item	Parts number	Parts name	Remarks	Area
	O 712	KTC3200/GL/-T	TRANSISTOR		
⚠	O 761	2SD2390/OPY/-F6	TRANSISTOR		
⚠	O 762	2SD2390/OPY/-F6	TRANSISTOR		
⚠	O 763	2SB1560/OPY/-F6	TRANSISTOR		
⚠	Q 764	2SB1560/OPY/-F6	TRANSISTOR		
	O 771	KTC3200/GL/-T	TRANSISTOR		
	O 772	KTC3200/GL/-T	TRANSISTOR		
	O 773	KTA1268/GL/-T	TRANSISTOR		
	O 774	KTA1268/GL/-T	TRANSISTOR		
	Q 781	2SD637/QR/	TRANSISTOR		
	O 782	2SD637/QR/	TRANSISTOR		
	O 791	KTA1268/GL/-T	TRANSISTOR		
	O 792	KTA1268/GL/-T	TRANSISTOR		
	O1701	2SC2240-BL/AB/T	TRANSISTOR		
	O1702	2SC2240-BL/AB/T	TRANSISTOR		
	O1703	KTA1268/GL/-T	TRANSISTOR		
	O1731	2SD637/QR/	TRANSISTOR		
⚠	O1751	2SD2390/OPY/-F6	TRANSISTOR		
⚠	O1752	2SB1560/OPY/-F6	TRANSISTOR		
	O1771	KTC3200/GL/-T	TRANSISTOR		
	O1772	KTA1268/GL/-T	TRANSISTOR		
	O1791	KTA1268/GL/-T	TRANSISTOR		
	O1801	2SC2240-BL/AB/T	TRANSISTOR		
	O1802	2SC2240-BL/AB/T	TRANSISTOR		
	O1803	2SC2240-BL/AB/T	TRANSISTOR		
	O1804	2SC2240-BL/AB/T	TRANSISTOR		
	O1805	KTA1268/GL/-T	TRANSISTOR		
	O1806	KTA1268/GL/-T	TRANSISTOR		
	O1831	2SD637/QR/	TRANSISTOR		
	Q1832	2SD637/QR/	TRANSISTOR		
⚠	O1851	2SD2390/OPY/-F6	TRANSISTOR		
⚠	O1852	2SD2390/OPY/-F6	TRANSISTOR		
⚠	O1853	2SB1560/OPY/-F6	TRANSISTOR		
⚠	O1854	2SB1560/OPY/-F6	TRANSISTOR		
	Q1871	KTC3200/GL/-T	TRANSISTOR		
	O1872	KTC3200/GL/-T	TRANSISTOR		
	O1873	KTA1268/GL/-T	TRANSISTOR		
	O1874	KTA1268/GL/-T	TRANSISTOR		
	Q1891	KTA1268/GL/-T	TRANSISTOR		
	O1892	KTA1268/GL/-T	TRANSISTOR		
	R 701	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
	R 702	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
	R 703	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 704	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 705	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W	
	R 706	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W	
	R 707	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W	
	R 708	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W	
	R 709	QRE141J-912Y	C RESISTOR	9.1K 5% 1/4W	
	R 710	QRE141J-912Y	C RESISTOR	9.1K 5% 1/4W	
	R 711	QRE141J-621Y	C RESISTOR	620 5% 1/4W	
	R 712	QRE141J-621Y	C RESISTOR	620 5% 1/4W	
	R 715	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 716	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 717	QRJ146J-562X	UNF C RESISTOR	5.6K 5% 1/4W	
	R 718	QRJ146J-562X	UNF C RESISTOR	5.6K 5% 1/4W	
	R 719	QRK126J-103X	UNF C RESISTOR	10K 5% 1/2W	
	R 720	QRK126J-103X	UNF C RESISTOR	10K 5% 1/2W	
	R 721	QRJ146J-151X	UNF C RESISTOR	150 5% 1/4W	
	R 722	QRJ146J-151X	UNF C RESISTOR	150 5% 1/4W	
	R 723	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R 724	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R 725	QRE141J-152Y	C RESISTOR	1.5K 5% 1/4W	

⚠	Item	Parts number	Parts name	Remarks	Area
	R 726	QRE141J-152Y	C RESISTOR	1.5K 5% 1/4W	
	R 727	QRE141J-333Y	C RESISTOR	33K 5% 1/4W	
	R 728	QRE141J-333Y	C RESISTOR	33K 5% 1/4W	
	R 729	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R 730	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R 731	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R 732	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R 733	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 734	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 761	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R 762	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R 763	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R 764	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R 771	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R 772	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R 773	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R 774	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R 775	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R 776	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R 777	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R 778	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R 779	QRZ0218-R22	EMIT RESISTOR	1/2W	
	R 780	QRZ0218-R22	EMIT RESISTOR	1/2W	
	R 781	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R 782	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R 783	QRE141J-621Y	C RESISTOR	620 5% 1/4W	
	R 784	QRE141J-621Y	C RESISTOR	620 5% 1/4W	
	R 787	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	R 788	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	R 789	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 790	QRE141J-471Y	C RESISTOR	470 5% 1/4W	
	R 791	QRJ125J-330	UNF C RESISTOR	33 5% 1/2W	
	R 792	QRJ125J-330	UNF C RESISTOR	33 5% 1/2W	
	R 793	QRL022J-100	UNF OMF REISTOR	10 5% 1/2W	
	R 794	QRL022J-100	UNF OMF RESISTOR	10 5% 1/2W	
	R 795	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 796	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R 797	QRE141J-153Y	C RESISTOR	15K 5% 1/4W	
	R 798	QRE141J-153Y	C RESISTOR	15K 5% 1/4W	
	R1701	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
	R1702	QRE141J-683Y	C RESISTOR	68K 5% 1/4W	
	R1703	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W	
	R1705	QRE141J-123Y	C RESISTOR	12K 5% 1/4W	
	R1711	QRE141J-331Y	C RESISTOR	330 5% 1/4W	
	R1712	QRE141J-563Y	C RESISTOR	56K 5% 1/4W	
	R1721	QRJ146J-221X	UNF C RESISTOR	220 5% 1/4W	
	R1722	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1723	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1724	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1725	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1731	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R1732	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1741	QRJ146J-221X	UNF C RESISTOR	220 5% 1/4W	
	R1751	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R1752	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R1753	QRZ0218-R22	EMIT RESISTOR	1/2W	
	R1761	QRJ125J-330	UNF C RESISTOR	33 5% 1/2W	
	R1762	QRL022J-100	UNF OMF RESISTOR	10 5% 1/2W	
	R1771	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1772	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1773	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R1774	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R1791	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	

■ **Electrical parts list (Power board)** **Block No. 03**

⚠	Item	Parts number	Parts name	Remarks	Area
	R1793	QRE141J-183Y	C RESISTOR	18K 5% 1/4W	
	R1795	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	R1801	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
	R1802	QRE141J-222Y	C RESISTOR	2.2K 5% 1/4W	
	R1803	QRE141J-683Y	C RESISTOR	68K 5% 1/4W	
	R1804	QRE141J-683Y	C RESISTOR	68K 5% 1/4W	
	R1805	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W	
	R1806	QRE141J-202Y	C RESISTOR	2.0K 5% 1/4W	
	R1809	QRE141J-123Y	C RESISTOR	12K 5% 1/4W	
	R1810	QRE141J-123Y	C RESISTOR	12K 5% 1/4W	
	R1811	QRE141J-331Y	C RESISTOR	330 5% 1/4W	
	R1812	QRE141J-331Y	C RESISTOR	330 5% 1/4W	
	R1813	QRE141J-563Y	C RESISTOR	56K 5% 1/4W	
	R1814	QRE141J-563Y	C RESISTOR	56K 5% 1/4W	
	R1821	QRJ146J-221X	UNF C RESISTOR	220 5% 1/4W	
	R1822	QRJ146J-221X	UNF C RESISTOR	220 5% 1/4W	
	R1823	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1824	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1825	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1826	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1827	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1828	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1829	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1830	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R1831	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R1832	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R1833	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1834	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1841	QRJ146J-221X	UNF C RESISTOR	220 5% 1/4W	
	R1842	QRJ146J-221X	UNF C RESISTOR	220 5% 1/4W	
	R1851	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R1852	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R1853	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R1854	QRJ146J-100X	UNF C RESISTOR	10 5% 1/4W	
	R1855	QRZ0218-R22	EMIT RESISTOR	1/2W	
	R1856	QRZ0218-R22	EMIT RESISTOR	1/2W	
	R1861	QRJ125J-330	UNF C RESISTOR	33 5% 1/2W	
	R1862	QRJ125J-330	UNF C RESISTOR	33 5% 1/2W	
	R1863	QRL022J-100	UNF MF RESISTOR	10 5% 1/2W	
	R1864	QRL022J-100	UNF OMF RESISTOR	10 5% 1/2W	
	R1871	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1872	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1873	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1874	QRE141J-391Y	C RESISTOR	390 5% 1/4W	
	R1875	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R1876	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R1877	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R1878	QRE141J-201Y	C RESISTOR	200 5% 1/4W	
	R1891	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R1892	QRE141J-102Y	C RESISTOR	1.0K 5% 1/4W	
	R1893	QRE141J-183Y	C RESISTOR	18K 5% 1/4W	
	R1894	QRE141J-183Y	C RESISTOR	18K 5% 1/4W	
	R1895	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	R1896	QRE141J-473Y	C RESISTOR	47K 5% 1/4W	
	TH731	QAD0012-202	THERMISTOR		
	TH783	QAD0012-202	THERMISTOR		
	TH784	QAD0012-202	THERMISTOR		
	TH831	QAD0012-202	THERMISTOR		
	TH832	QAD0012-202	THERMISTOR		
	VR787	QVP0008-501Z	SEMI V RESISTOR		
	VR788	QVP0008-501Z	SEMI V RESISTOR		

■ **Electrical parts list (Input board)** **Block No. 04**

⚠	Item	Parts number	Parts name	Remarks	Area
	C 201	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 202	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 203	QETN0JM-477Z	E CAPACITOR	470MF 20% 6.3V	
	C 204	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 205	QETN0JM-477Z	E CAPACITOR	470MF 20% 6.3V	
	C 206	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 207	QETN0JM-477Z	E CAPACITOR	470MF 20% 6.3V	
	C 208	QETN1CM-476Z	E CAPACITOR	47MF 20% 16V	
	C 209	QCF31HZ-103Z	C CAPACITOR	.010MF +80:-20%	
	C 210	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 211	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 212	QETN1CM-476Z	E CAPACITOR	47MF 20% 16V	
	C 213	QCF31HZ-103Z	C CAPACITOR	.010MF +80:-20%	
	C 214	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 215	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 216	QDX31EM-473Z	C CAPACITOR		
	C 217	QETN1AM-477Z	E CAPACITOR	470MF 20% 10V	
	C 218	QCZ0202-155Z	ML C CAPACITOR	1.5MF	
	C 219	QDC31HJ-150Z	C CAPACITOR		
	C 220	QDC31HJ-100Z	C CAPACITOR		
	C 221	QDC31HJ-470Z	C CAPACITOR		
	C 222	QDC31HJ-270Z	C CAPACITOR		
	C 223	NCB31HK-102X	C CAPACITOR		
	C 224	NCS31HJ-271X	C CAPACITOR		
	C 225	NCS31HJ-121X	C CAPACITOR		
	C 226	NCS31HJ-470X	C CAPACITOR		
	C 241	QDX31EM-473Z	C CAPACITOR		
	C 242	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 244	QDX31EM-473Z	C CAPACITOR		
	C 245	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 246	QDX31EM-473Z	C CAPACITOR		
	C 247	QETN0JM-477Z	E CAPACITOR	470MF 20% 6.3V	
	C 249	QDX31EM-473Z	C CAPACITOR		
	C 250	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 251	QDX31EM-473Z	C CAPACITOR		
	C 252	QETN0JM-477Z	E CAPACITOR	470MF 20% 6.3V	
	C 253	NCS31HJ-100X	C CAPACITOR		
	C 254	QDX31EM-473Z	C CAPACITOR		
	C 255	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 256	QCF31HZ-103Z	C CAPACITOR	.010MF +80:-20%	
	C 257	QETN1CM-476Z	E CAPACITOR	47MF 20% 16V	
	C 258	QCF31HZ-103Z	C CAPACITOR	.010MF +80:-20%	
	C 259	QETN1CM-476Z	E CAPACITOR	47MF 20% 16V	
	C 260	QDX31EM-473Z	C CAPACITOR		
	C 261	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 268	NCS31HJ-470X	C CAPACITOR		
	C 269	NCS31HJ-470X	C CAPACITOR		
	C 270	NCS31HJ-101X	C CAPACITOR		
	C 271	NCS31HJ-101X	C CAPACITOR		
	C 272	QDX31EM-473Z	C CAPACITOR		
	C 273	QDX31EM-473Z	C CAPACITOR		
	C 274	QETN0JM-477Z	E CAPACITOR	470MF 20% 6.3V	
	C 275	NCS31HJ-470X	C CAPACITOR		
	C 276	NCS31HJ-470X	C CAPACITOR		
	C 277	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 301	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 302	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 303	NCS31HJ-101X	C CAPACITOR		
	C 304	NCS31HJ-101X	C CAPACITOR		
	C 305	QFLC1HJ-182Z	M CAPACITOR	1800PF 5% 50V	
	C 306	QFLC1HJ-182Z	M CAPACITOR	1800PF 5% 50V	
	C 307	QFLC1HJ-682Z	M CAPACITOR	6800PF 5% 50V	
	C 308	QFLC1HJ-682Z	M CAPACITOR	6800PF 5% 50V	

⚠	Item	Parts number	Parts name	Remarks	Area
	C 309	NCS31HJ-101X	C CAPACITOR		
	C 310	NCS31HJ-101X	C CAPACITOR		
	C 311	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 312	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 313	QETN1AM-107Z	E CAPACITOR	100MF 20% 10V	
	C 314	QETN1AM-107Z	E CAPACITOR	100MF 20% 10V	
	C 315	QETN1CM-476Z	E CAPACITOR	47MF 20% 16V	
	C 316	QETN1CM-476Z	E CAPACITOR	47MF 20% 16V	
	C 321	NCB31HK-221X	C CAPACITOR		
	C 322	NCB31HK-221X	C CAPACITOR		
	C 323	NCB31HK-221X	C CAPACITOR		
	C 324	NCB31HK-221X	C CAPACITOR		
	C 325	NCB31HK-221X	C CAPACITOR		
	C 326	NCB31HK-221X	C CAPACITOR		
	C 327	NCB31HK-221X	C CAPACITOR		
	C 328	NCB31HK-221X	C CAPACITOR		
	C 329	NCB31HK-221X	C CAPACITOR		
	C 330	NCB31HK-221X	C CAPACITOR		
	C 331	NCB31HK-221X	C CAPACITOR		
	C 332	NCB31HK-221X	C CAPACITOR		
	C 333	NCB31HK-561X	C CAPACITOR		
	C 334	NCB31HK-561X	C CAPACITOR		
	C 335	QETN1EM-226Z	E CAPACITOR	22MF 20% 25V	
	C 336	QETN1EM-226Z	E CAPACITOR	22MF 20% 25V	
	C 339	NCB31HK-561X	C CAPACITOR		
	C 341	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C 342	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C 343	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C 344	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C 361	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 362	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 363	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 364	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C 371	NCB31HK-221X	C CAPACITOR		
	C 372	NCB31HK-221X	C CAPACITOR		
	C 373	NCB31HK-221X	C CAPACITOR		
	C 374	NCB31HK-221X	C CAPACITOR		
	C 375	NCB31HK-221X	C CAPACITOR		
	C 376	NCB31HK-221X	C CAPACITOR		
	C 377	NCB31HK-221X	C CAPACITOR		
	C 378	NCB31HK-221X	C CAPACITOR		
	C 379	NCB31HK-221X	C CAPACITOR		
	C 380	NCB31HK-221X	C CAPACITOR		
	C 381	NCB31HK-221X	C CAPACITOR		
	C 382	NCB31HK-221X	C CAPACITOR		
	C 385	QETN1EM-226Z	E CAPACITOR	22MF 20% 25V	
	C 386	QETN1EM-226Z	E CAPACITOR	22MF 20% 25V	
	C 389	NCB31HK-561X	C CAPACITOR		
	C 391	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C 392	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C 393	NCB31HK-122X	C CAPACITOR		
	C 394	NCB31HK-122X	C CAPACITOR		
	C 395	NCS31HJ-121X	C CAPACITOR		
	C 396	NCS31HJ-121X	C CAPACITOR		
	C 397	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	C 398	QETN1HM-106Z	E CAPACITOR	10MF 20% 50V	
	CN200	QGB2510K1-11	CONNECTOR		
	CN204	QGB1214K1-08S	CONNECTOR		
	CN205	QGB1214J1-08S	CONNECTOR		
	CN206	QGA2501F1-02	CONNECTOR		
	CN240	QGB2510K1-12	CONNECTOR		
	CN242	QGB1214K1-10S	CONNECTOR		
	CN243	QGB1214J1-10S	CONNECTOR		

■ **Electrical parts list (Input board)** **Block No. 04**

⚠	Item	Parts number	Parts name	Remarks	Area
	CN244	QGA2501F1-04	CONNECTOR		
	CN311	QGB2510K1-14	CONNECTOR		
	CN313	QGB2510K1-13	CONNECTOR		
	CN351	QGB1214K1-16S	CONNECTOR		
	CN361	QGB1214J1-16S	CONNECTOR		
	CN371	QGB1214K1-14S	CONNECTOR		
	CN381	QGB1214J1-14S	CONNECTOR		
	CN416	QGA2501F1-06	CONNECTOR		
	CN501	QGB1214J1-12S	CONNECTOR		
	CN731	QJP001-032301	SHI CR C-B WIRE		
	CN732	WJP0026-001A	CONNECTOR		
	C1301	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	C1302	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	C1303	NCB31HK-221X	C CAPACITOR		
	C1305	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	C1306	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	C1307	QETN1CM-476Z	E CAPACITOR	47MF 20% 16V	
	C1311	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1312	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1313	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1314	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1315	QER61HM-224Z	E CAPACITOR	.22MF 20% 50V	
	C1316	QER61HM-224Z	E CAPACITOR	.22MF 20% 50V	
	C1319	NCB31HK-221X	C CAPACITOR		
	C1321	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1322	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1323	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1324	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1325	QER61HM-224Z	E CAPACITOR	.22MF 20% 50V	
	C1326	QER61HM-224Z	E CAPACITOR	.22MF 20% 50V	
	C1329	NCB31HK-221X	C CAPACITOR		
	C1331	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1332	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1333	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1334	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1339	NCB31HK-221X	C CAPACITOR		
	C1341	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1342	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1343	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	C1344	QETN1EM-476Z	E CAPACITOR	47MF 20% 25V	
	C1345	NCS31HJ-391X	C CAPACITOR		
	C1346	NCB31EK-223X	C CAPACITOR		
	C1361	NCB31HK-681X	C CAPACITOR		
	C1362	NCB31HK-681X	C CAPACITOR		
	C1363	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1364	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1365	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1366	QETN1HM-475Z	E CAPACITOR	4.7MF 20% 50V	
	C1370	NCB31HK-221X	C CAPACITOR		
	C1371	NCB31HK-221X	C CAPACITOR		
	C1372	NCB31HK-221X	C CAPACITOR		
	D 200	1SS133-T1	SI DIODE		
	D 201	1SS133-T1	SI DIODE		
	D 240	1SS133-T1	SI DIODE		
	D 241	1SS133-T1	SI DIODE		
	HL203	VYH7653-005	IC HOLDER		
	IC201	BA7625	IC		
	IC202	NJM2285V-W	IC		
	IC203	MB90088PF-131	IC		
	IC241	BA7626	IC		
	IC242	BA7625	IC		
	IC301	NJM4580D-D	IC		
	IC302	TC9164AF-X	IC		

⚠	Item	Parts number	Parts name	Remarks	Area
	IC303	BA15218F-XE	IC		
	IC304	BA15218F-XE	IC		
	IC371	TC9163AF-X	IC		
	IC372	BA15218F-XE	IC		
	IC380	TC9162AN	IC		
	IC381	TC9459F-X	IC		
	IC382	TC9459F-X	IC		
	IC383	TC9459F-X	IC		
	IC385	BA15218F-XE	IC		
	IC386	BA15218F-XE	IC		
	J 201	QNN0078-001	PIN JACK		
	J 202	QNN0011-001	PIN JACK		
	J 203	QNN0011-001	PIN JACK		
	J 241	QND0002-001	S-CONNECTOR		
	J 242	QND0028-001	DIN CONNECTOR		
	J 243	QND0088-001	S JACK		
	J 301	QNN0056-001	PIN JACK		
	J 302	QNN0056-001	PIN JACK		
	J 303	QNN0058-001	PIN JACK		
	J 371	QNN0056-001	PIN JACK		
	J 372	QNN0056-001	PIN JACK		
	J 373	QNN0056-001	PIN JACK		
	J1340	QNN0060-001	PIN JACK		
	J1360	QNN0390-001	PIN JACK		
	J1370	QNS0083-001	3.5 JACK		
	J1371	QNS0077-001	3.5 JACK		
	L 200	NQL085J-220X	INDUCTOR		
	O 200	KTA1267/YG/-T	TRANSISTOR		
	O 201	KTA1267/YG/-T	TRANSISTOR		
	Q 202	KRC110M-T	TRANSISTOR		
	O 203	KRC107M-T	D TRANSISTOR		
	O 204	KTA1267/YG/-T	TRANSISTOR		
	O 205	KTA1267/YG/-T	TRANSISTOR		
	O 206	KTA1267/YG/-T	TRANSISTOR		
	Q 208	DTC123YSA-T	D TRANSISTOR		
	O 240	KTA1267/YG/-T	TRANSISTOR		
	O 241	KTA1267/YG/-T	TRANSISTOR		
	O 242	KTA1267/YG/-T	TRANSISTOR		
	Q 243	KTA1267/YG/-T	TRANSISTOR		
	O 244	KRC110M-T	TRANSISTOR		
	O 245	KRC110M-T	TRANSISTOR		
	O 246	KRC107M-T	D TRANSISTOR		
	O 247	KRC107M-T	D TRANSISTOR		
	Q1307	KRA104M-T	D TRANSISTOR		
	O1313	2SC3576-JVC-T	TRANSISTOR		
	Q1314	2SC3576-JVC-T	TRANSISTOR		
	O1323	2SC3576-JVC-T	TRANSISTOR		
	O1333	2SC3576-JVC-T	TRANSISTOR		
	Q1334	2SC3576-JVC-T	TRANSISTOR		
	O1341	2SC3576-JVC-T	TRANSISTOR		
	O1342	2SC3576-JVC-T	TRANSISTOR		
	O1343	KRA104M-T	D TRANSISOTR		
	R 200	NRSA63J-750X	MG RESISTOR		
	R 201	NRSA63J-750X	MG RESISTOR		
	R 202	NRSA63J-750X	MG RESISTOR		
	R 203	NRSA63J-750X	MG RESISTOR		
	R 204	NRSA63J-750X	MG RESISTOR		
	R 205	NRSA63J-750X	MG RESISTOR		
	R 206	NRSA63J-750X	MG RESISTOR		
	R 207	NRSA63J-331X	MG RESISTOR		
	R 208	NRSA63J-331X	MG RESISTOR		
	R 209	NRSA63J-473X	MG RESISTOR		
	R 210	NRSA63J-331X	MG RESISTOR		

■ **Electrical parts list (Input board)** **Block No. 04**

⚠	Item	Parts number	Parts name	Remarks	Area
	R 211	NRSA63J-473X	MG RESISTOR		
	R 212	NRSA63J-331X	MG RESISTOR		
	R 213	NRSA63J-473X	MG RESISTOR		
	R 214	NRSA63J-151X	MG RESISTOR		
	R 215	NRSA63J-151X	MG RESISTOR		
	R 216	NRSA63J-301X	MG RESISTOR		
	R 217	NRSA63J-103X	MG RESISTOR		
	R 218	NRSA63J-331X	MG RESISTOR		
	R 219	NRSA63J-101X	MG RESISTOR		
	R 220	NRSA63J-151X	MG RESISTOR		
	R 221	NRSA63J-151X	MG RESISTOR		
	R 222	NRSA63J-561X	MG RESISTOR		
	R 223	NRSA63J-561X	MG RESISTOR		
	R 224	NRSA63J-561X	MG RESISTOR		
⚠	R 225	QRJ146J-2R2X	UNF C RESISTOR	2.2 5% 1/4W	
	R 232	NRSA63J-470X	MG RESISTOR		
	R 240	NRSA63J-750X	MG RESISTOR		
	R 241	NRSA63J-750X	MG RESISTOR		
	R 242	NRSA63J-750X	MG RESISTOR		
	R 243	NRSA63J-750X	MG RESISTOR		
	R 244	NRSA63J-750X	MG RESISTOR		
	R 245	NRSA63J-750X	MG RESISTOR		
	R 246	NRSA63J-750X	MG RESISTOR		
	R 247	NRSA63J-750X	MG RESISTOR		
	R 248	NRSA63J-151X	MG RESISTOR		
	R 249	NRSA63J-151X	MG RESISTOR		
	R 250	NRSA63J-151X	MG RESISTOR		
	R 251	NRSA63J-151X	MG RESISTOR		
	R 253	NRSA63J-153X	MG RESISTOR		
	R 254	NRSA63J-153X	MG RESISTOR		
	R 255	NRSA63J-153X	MG RESISTOR		
	R 266	NRSA63J-750X	MG RESISTOR		
	R 267	NRSA63J-473X	MG RESISTOR		
	R 268	NRSA63J-750X	MG RESISTOR		
	R 269	NRSA63J-473X	MG RESISTOR		
⚠	R 271	QRJ146J-3R3X	UNF C RESCITOR	3.3 5% 1/4W	
	R 272	NRSA63J-750X	MG RESISTOR		
	R 273	NRSA63J-473X	MG RESISTOR		
	R 274	NRSA63J-750X	MG RESISTOR		
	R 275	NRSA63J-750X	MG RESISTOR		
	R 276	NRSA63J-750X	MG RESISTOR		
	R 280	NRSA63J-301X	MG RESISTOR		
	R 281	NRSA63J-301X	MG RESISTOR		
	R 282	NRSA63J-103X	MG RESISTOR		
	R 283	NRSA63J-103X	MG RESISTOR		
	R 284	NRSA63J-301X	MG RESISTOR		
	R 285	NRSA63J-301X	MG RESISTOR		
	R 301	NRSA63J-222X	MG RESISTOR		
	R 302	NRSA63J-222X	MG RESISTOR		
	R 303	NRSA63J-473X	MG RESISTOR		
	R 304	NRSA63J-473X	MG RESISTOR		
	R 305	NRSA63J-621X	MG RESISTOR		
	R 306	NRSA63J-621X	MG RESISTOR		
	R 307	NRSA63J-393X	MG RESISTOR		
	R 308	NRSA63J-393X	MG RESISTOR		
	R 309	NRSA63J-474X	MG RESISTOR		
	R 310	NRSA63J-474X	MG RESISTOR		
	R 311	NRSA63J-104X	MG RESISTOR		
	R 312	NRSA63J-104X	MG RESISTOR		
⚠	R 315	QRJ146J-331X	UNF C RESISTOR	330 5% 1/4W	
⚠	R 316	QRJ146J-331X	UNF C RESISTOR	330 5% 1/4W	
	R 323	NRSA63J-471X	MG RESISTOR		
	R 324	NRSA63J-471X	MG RESISTOR		

⚠	Item	Parts number	Parts name	Remarks	Area
	R 325	NRSA63J-471X	MG RESISTOR		
	R 326	NRSA63J-471X	MG RESISTOR		
	R 327	NRSA63J-471X	MG RESISTOR		
	R 328	NRSA63J-471X	MG RESISTOR		
	R 329	NRSA63J-471X	MG RESISTOR		
	R 330	NRSA63J-471X	MG RESISTOR		
	R 331	NRSA63J-471X	MG RESISTOR		
	R 332	NRSA63J-471X	MG RESISTOR		
	R 333	NRSA63J-471X	MG RESISTOR		
	R 334	NRSA63J-471X	MG RESISTOR		
⚠	R 335	QRZ9005-680X	F RESISTOR	68 1/0W	
⚠	R 336	QRZ9005-680X	F RESISTOR	68 1/0W	
	R 341	NRSA63J-104X	MG RESISTOR		
	R 342	NRSA63J-104X	MG RESISTOR		
	R 343	NRSA63J-104X	MG RESISTOR		
	R 344	NRSA63J-104X	MG RESISTOR		
	R 345	NRSA63J-104X	MG RESISTOR		
	R 346	NRSA63J-104X	MG RESISTOR		
	R 361	NRSA63J-104X	MG RESISTOR		
	R 362	NRSA63J-104X	MG RESISTOR		
	R 363	NRSA63J-104X	MG RESISTOR		
	R 364	NRSA63J-104X	MG RESISTOR		
	R 365	NRSA63J-104X	MG RESISTOR		
	R 366	NRSA63J-104X	MG RESISTOR		
	R 371	NRSA63J-471X	MG RESISTOR		
	R 372	NRSA63J-471X	MG RESISTOR		
	R 373	NRSA63J-471X	MG RESISTOR		
	R 374	NRSA63J-471X	MG RESISTOR		
	R 375	NRSA63J-471X	MG RESISTOR		
	R 376	NRSA63J-471X	MG RESISTOR		
	R 377	NRSA63J-471X	MG RESISTOR		
	R 378	NRSA63J-471X	MG RESISTOR		
	R 379	NRSA63J-471X	MG RESISTOR		
	R 380	NRSA63J-471X	MG RESISTOR		
	R 381	NRSA63J-471X	MG RESISTOR		
	R 382	NRSA63J-471X	MG RESISTOR		
⚠	R 385	QRZ9005-680X	F RESISTOR	68 1/0W	
⚠	R 386	QRZ9005-680X	F RESISTOR	68 1/0W	
	R 387	NRSA63J-471X	MG RESISTOR		
	R 388	NRSA63J-471X	MG RESISTOR		
	R 389	NRSA63J-471X	MG RESISTOR		
	R 390	NRSA63J-471X	MG RESISTOR		
	R 391	NRSA63J-512X	MG RESISTOR		
	R 392	NRSA63J-512X	MG RESISTOR		
	R 393	NRSA63J-103X	MG RESISTOR		
	R 394	NRSA63J-103X	MG RESISTOR		
	R 395	NRSA63J-512X	MG RESISTOR		
	R 396	NRSA63J-512X	MG RESISTOR		
	R 397	NRSA63J-104X	MG RESISTOR		
	R 398	NRSA63J-104X	MG RESISTOR		
⚠	R1301	QRZ9005-680X	F RESISTOR	68 1/0W	
⚠	R1302	QRZ9005-680X	F RESISTOR	68 1/0W	
	R1303	NRSA63J-122X	MG RESISTOR		
	R1304	NRSA63J-122X	MG RESISTOR		
⚠	R1305	QRZ9005-680X	F RESISTOR	68 1/0W	
⚠	R1306	QRZ9005-680X	F RESISTOR	68 1/0W	
	R1307	NRSA63J-102X	MG RESISTOR		
	R1311	NRSA63J-104X	MG RESISTOR		
	R1312	NRSA63J-104X	MG RESISTOR		
	R1313	NRSA63J-102X	MG RESISTOR		
	R1314	NRSA63J-103X	MG RESISTOR		
	R1315	NRSA63J-103X	MG RESISTOR		
	R1316	NRSA63J-102X	MG RESISTOR		

■ **Electrical parts list (Input board)** **Block No. 04**

⚠	Item	Parts number	Parts name	Remarks	Area
	R1321	NRSA63J-104X	MG RESISTOR		
	R1322	NRSA63J-104X	MG RESISTOR		
	R1323	NRSA63J-102X	MG RESISTOR		
	R1324	NRSA63J-103X	MG RESISTOR		
	R1329	NRSA63J-0R0X	MG RESISTOR		
	R1330	NRSA63J-0R0X	MG RESISTOR		
	R1331	NRSA63J-104X	MG RESISTOR		
	R1332	NRSA63J-104X	MG RESISTOR		
	R1333	NRSA63J-102X	MG RESISTOR		
	R1334	NRSA63J-103X	MG RESISTOR		
	R1335	NRSA63J-103X	MG RESISTOR		
	R1336	NRSA63J-102X	MG RESISTOR		
	R1341	NRSA63J-104X	MG RESISTOR		
	R1342	NRSA63J-102X	MG RESISTOR		
	R1343	NRSA63J-183X	MG RESISTOR		
	R1344	NRSA63J-104X	MG RESISTOR		
	R1345	NRSA63J-471X	MG RESISTOR		
	R1346	NRSA63J-103X	MG RESISTOR		
	R1347	NRSA63J-471X	MG RESISTOR		
	R1348	NRSA63J-103X	MG RESISTOR		
	R1349	NRSA63J-474X	MG RESISTOR		
⚠	R1350	QRZ9005-680X	F RESISTOR	68 1/0W	
⚠	R1351	QRZ9005-680X	F RESISTOR	68 1/0W	
	R1355	NRSA63J-222X	MG RESISTOR		
	R1356	NRSA63J-222X	MG RESISTOR		
	R1357	NRSA63J-392X	MG RESISTOR		
	R1358	NRSA63J-392X	MG RESISTOR		
	R1361	NRSA63J-561X	MG RESISTOR		
	R1362	NRSA63J-561X	MG RESISTOR		
	R1363	NRSA63J-104X	MG RESISTOR		
	R1364	NRSA63J-104X	MG RESISTOR		
	R1365	NRSA63J-104X	MG RESISTOR		
	R1366	NRSA63J-104X	MG RESISTOR		
	R1367	NRSA63J-104X	MG RESISTOR		
	R1368	NRSA63J-104X	MG RESISTOR		
	R1370	NRSA63J-471X	MG RESISTOR		
	R1371	NRSA63J-221X	MG RESISTOR		
	R1372	NRSA63J-101X	MG RESISTOR		
	R1373	NRSA63J-221X	MG RESISTOR		
	R1374	NRSA63J-221X	MG RESISTOR		
	X 200	QAX0261-001Z	CRYSTAL	PAL ONLY	

■ **Electrical parts list (DSP board)** **Block No. 05**

⚠	Item	Parts number	Parts name	Remarks	Area
	C 571	NCB31HK-103X	C CAPACITOR		
	C 573	NCF31CZ-104X	C CAPACITOR		
	C 577	NCS31HJ-101X	C CAPACITOR		
	C 579	NCS31HJ-101X	C CAPACITOR		
	C 581	NEA71CM-106X	E CAPACITOR		
	C 582	NEA71CM-106X	E CAPACITOR		
	C 583	NEA70JM-476X	E CAPACITOR		
	C 584	NCB31CK-104X	C CAPACITOR		
	C 587	NCF31CZ-104X	C CAPACITOR		
	C 588	NEA70JM-476X	E CAPACITOR		
	C 589	NCF31CZ-104X	C CAPACITOR		
	C 590	NEA70GM-107X	E CAPACITOR		
	CN581	QGB1214K3-12W	CONNECTOR		
	CN587	QGB2510K1-07	CONNECTOR		
	C2001	NEA71EM-475X	E CAPACITOR		
	C2002	NEA71EM-475X	E CAPACITOR		
	C2003	NCB31HK-122X	C CAPACITOR		
	C2004	NCB31HK-122X	C CAPACITOR		
	C2005	NCS31HJ-121X	C CAPACITOR		
	C2006	NCS31HJ-121X	C CAPACITOR		
	C2007	NCS31HJ-391X	C CAPACITOR		
	C2008	NCS31HJ-391X	C CAPACITOR		
	C2009	NCF31CZ-104X	C CAPACITOR		
	C2010	NCF31CZ-104X	C CAPACITOR		
	C2013	NCS31HJ-330X	C CAPACITOR		
	C2014	NCS31HJ-330X	C CAPACITOR		
	C2018	NEA70JM-476X	E CAPACITOR		
	C2019	NCF31CZ-104X	C CAPACITOR		
	C2020	NCF31CZ-104X	C CAPACITOR		
	C2101	NCB31HK-103X	C CAPACITOR		
	C2107	NEA71EM-475X	E CAPACITOR		
	C2133	NCB31EK-223X	C CAPACITOR		
	C2134	NCB31EK-223X	C CAPACITOR		
	C2135	NEA71CM-106X	E CAPACITOR		
	C2136	NEA71CM-106X	E CAPACITOR		
	C2137	NEA71EM-475X	E CAPACITOR		
	C2138	NEA71EM-475X	E CAPACITOR		
	C2157	NEA71HM-225X	E CAPACITOR		
	C2158	NCS31HJ-330X	C CAPACITOR		
	C2187	NEA71HM-225X	E CAPACITOR		
	C2189	NCS31HJ-330X	C CAPACITOR		
	C2201	NCB31HK-102X	C CAPACITOR		
	C2202	NCB31HK-102X	C CAPACITOR		
	C2207	NEA71HM-225X	E CAPACITOR		
	C2208	NEA71HM-225X	E CAPACITOR		
	C2230	NEA71EM-475X	E CAPACITOR		
	C2237	NCS31HJ-330X	C CAPACITOR		
	C2238	NCS31HJ-330X	C CAPACITOR		
	C2251	NCF31CZ-104X	C CAPACITOR		
	C2252	NCF31CZ-104X	C CAPACITOR		
	C2253	NCF31CZ-104X	C CAPACITOR		
	C2254	NCF31CZ-104X	C CAPACITOR		
	C2255	NCF31CZ-104X	C CAPACITOR		
	C2256	NCF31CZ-104X	C CAPACITOR		
	C2257	NEA71HM-225X	E CAPACITOR		
	C2258	NEA71HM-225X	E CAPACITOR		
	C2261	NEA71EM-475X	E CAPACITOR		
	C2262	NEA71EM-475X	E CAPACITOR		
	C2283	NCS31HJ-330X	C CAPACITOR		
	C2284	NCS31HJ-330X	C CAPACITOR		
	C2301	NCB31HK-102X	C CAPACITOR		
	C2302	NCB31HK-102X	C CAPACITOR		
	C2307	NEA71EM-475X	E CAPACITOR		

⚠	Item	Parts number	Parts name	Remarks	Area
	C2308	NEA71EM-475X	E CAPACITOR		
	C2347	NCS31HJ-330X	C CAPACITOR		
	C2348	NCS31HJ-330X	C CAPACITOR		
	C2349	NCF31CZ-104X	C CAPACITOR		
	C2350	NCF31CZ-104X	C CAPACITOR		
	C2351	NEA71HM-105X	E CAPACITOR		
	C2352	NEA71HM-105X	E CAPACITOR		
	C2353	NCS31HJ-330X	C CAPACITOR		
	C2354	NCS31HJ-330X	C CAPACITOR		
	C2355	NCF31CZ-104X	C CAPACITOR		
	C2356	NCF31CZ-104X	C CAPACITOR		
	C2357	NEA71EM-475X	E CAPACITOR		
	C2358	NEA71EM-475X	E CAPACITOR		
	C2401	NCB31HK-102X	C CAPACITOR		
	C2407	NEA71EM-475X	E CAPACITOR		
	C2427	NEA71HM-225X	E CAPACITOR		
	C2433	NCS31HJ-330X	C CAPACITOR		
	C2439	NCF31CZ-104X	C CAPACITOR		
	C2440	NCF31CZ-104X	C CAPACITOR		
	C2441	NCF31CZ-104X	C CAPACITOR		
	C2442	NCF31CZ-104X	C CAPACITOR		
	C2481	NEA70JM-476X	E CAPACITOR		
	C2501	NCB31HK-103X	C CAPACITOR		
	C2502	NCB31HK-103X	C CAPACITOR		
	C2503	NCB31HK-103X	C CAPACITOR		
	C2504	NCB31HK-103X	C CAPACITOR		
	C2505	NCB31HK-103X	C CAPACITOR		
	C2506	NCB31HK-103X	C CAPACITOR		
	C2507	NCB31HK-103X	C CAPACITOR		
	C2508	NCB31HK-103X	C CAPACITOR		
	C2509	NCB31HK-103X	C CAPACITOR		
	C2510	NCB31HK-103X	C CAPACITOR		
	C2511	NCB31HK-103X	C CAPACITOR		
	C2512	NCB31HK-103X	C CAPACITOR		
	C2513	NCB31HK-103X	C CAPACITOR		
	C2514	NCB31HK-103X	C CAPACITOR		
	C2515	NCB31HK-103X	C CAPACITOR		
	C2516	NCB31HK-103X	C CAPACITOR		
	C2517	NCB31HK-103X	C CAPACITOR		
	C2518	NCB31HK-103X	C CAPACITOR		
	C2519	NCB31HK-103X	C CAPACITOR		
	C2520	NCB31HK-103X	C CAPACITOR		
	C2521	NCB31HK-103X	C CAPACITOR		
	C2522	NCB31HK-103X	C CAPACITOR		
	C2523	NCF31CZ-104X	C CAPACITOR		
	C2529	NEA70GM-107X	E CAPACITOR		
	C2532	NEA70GM-107X	E CAPACITOR		
	C2533	NCF31CZ-104X	C CAPACITOR		
	C2534	NCF31CZ-104X	C CAPACITOR		
	C2535	NEA70GM-107X	E CAPACITOR		
	C2536	NCF31CZ-104X	C CAPACITOR		
	C2551	NCS31HJ-270X	C CAPACITOR		
	C2552	NCS31HJ-270X	C CAPACITOR		
	C2553	NEA70GM-107X	E CAPACITOR		
	C2555	NCF31CZ-104X	C CAPACITOR		
	C2556	NCF31CZ-104X	C CAPACITOR		
	C2557	NCS31HJ-330X	C CAPACITOR		
	C2560	NCF31CZ-104X	C CAPACITOR		
	C2561	NCF31CZ-104X	C CAPACITOR		
	C2562	NCF31CZ-104X	C CAPACITOR		
	C2563	NCF31CZ-104X	C CAPACITOR		
	C2564	NCS31HJ-101X	C CAPACITOR		
	C2568	NEA71HM-105X	E CAPACITOR		

■ **Electrical parts list (DSP board)** **Block No. 05**

⚠	Item	Parts number	Parts name	Remarks	Area
	C2601	NCB31CK-104X	C CAPACITOR		
⚠	C2602	NCB31CK-104X	C CAPACITOR		
	C2701	NCB31HK-221X	C CAPACITOR		
	C2702	NCB31HK-221X	C CAPACITOR		
	C2703	NEA70JM-476X	E CAPACITOR		
	C2704	NEA70JM-476X	E CAPACITOR		
	C2705	NCF31CZ-104X	C CAPACITOR		
	C2706	NCF31CZ-104X	C CAPACITOR		
	C2707	NCB31CK-104X	C CAPACITOR		
	C2710	NEA70JM-476X	E CAPACITOR		
	C2712	NCF31CZ-104X	C CAPACITOR		
	EP561	E409182-001SM	GRAND TERMINAL		
	IC501	XCA56367PV150	IC		
	IC502	TC7S04FU-X	IC		
	IC503	TC7S04FU-X	IC		
	IC505	PQ070XZ1HZ-X	IC		
	IC511	W24L010AJ-12-X	IC		
	IC521	BA15218F-XE	IC		
	IC522	BA15218F-XE	IC		
	IC523	BA15218F-XE	IC		
	IC524	BA15218F-XE	IC		
	IC525	BA15218F-XE	IC		
	IC526	BA15218F-XE	IC		
	IC527	BA15218F-XE	IC		
	IC528	BA15218F-XE	IC		
	IC529	BA15218F-XE	IC		
	IC551	AK4112AVF-X	IC		
	IC571	AK4527BVQ	IC		
	IC581	UPD784215AGC152	IC		
	IC582	TC7SET32FU-X	IC		
	IC583	PQ3DZ53-X	IC		
	J 564	QNN0347-001	PIN JACK		
⚠	K2606	NQR0269-004X	FERRITE BEADS		
	LC501	NQR0322-001X	EMI FILTER		
	LC502	NQR0322-001X	EMI FILTER		
	LC503	NQR0322-001X	EMI FILTER		
	LC551	NQR0322-001X	EMI FILTER		
	O 570	DTC114YE-X	TRANSISTOR		
	Q 572	DTC114YE-X	TRANSISTOR		
	O2101	2SD1328/ST/-X	TRANSISTOR		
	O2151	DTA114YE-X	TRANSISTOR		
	O2152	DTA114YE-X	TRANSISTOR		
	O2153	DTA114YE-X	TRANSISTOR		
	Q2154	DTA114YE-X	TRANSISTOR		
	O2155	DTA114YE-X	TRANSISTOR		
	Q2156	DTA114YE-X	TRANSISTOR		
	O2157	DTA114YE-X	TRANSISTOR		
	O2163	2SD1328/ST/-X	TRANSISTOR		
	Q2164	2SD1328/ST/-X	TRANSISTOR		
	O2165	2SD1328/ST/-X	TRANSISTOR		
	O2201	2SD1328/ST/-X	TRANSISTOR		
	O2202	2SD1328/ST/-X	TRANSISTOR		
	O2273	2SD1328/ST/-X	TRANSISTOR		
	O2274	2SD1328/ST/-X	TRANSISTOR		
	O2301	2SD1328/ST/-X	TRANSISTOR		
	O2302	2SD1328/ST/-X	TRANSISTOR		
	O2363	2SD1328/ST/-X	TRANSISTOR		
	O2364	2SD1328/ST/-X	TRANSISTOR		
	O2401	2SD1328/ST/-X	TRANSISTOR		
	O2431	2SD1328/ST/-X	TRANSISTOR		
	R 570	NRSA63J-103X	MG RESISTOR		
	R 573	NRSA63J-432X	MG RESISTOR		
	R 574	NRSA63J-432X	MG RESISTOR		

⚠	Item	Parts number	Parts name	Remarks	Area
	R 575	NRSA63J-432X	MG RESISTOR		
	R 576	NRSA63J-432X	MG RESISTOR		
	R 577	NRSA63J-822X	MG RESISTOR		
	R 578	NRSA63J-822X	MG RESISTOR		
	R 579	NRSA63J-822X	MG RESISTOR		
	R 580	NRSA63J-822X	MG RESISTOR		
	R 582	NRSA63J-103X	MG RESISTOR		
	R2001	NRSA63J-104X	MG RESISTOR		
	R2002	NRSA63J-104X	MG RESISTOR		
	R2003	NRSA63J-103X	MG RESISTOR		
	R2004	NRSA63J-103X	MG RESISTOR		
	R2005	NRSA63J-103X	MG RESISTOR		
	R2006	NRSA63J-103X	MG RESISTOR		
	R2007	NRSA63J-103X	MG RESISTOR		
	R2008	NRSA63J-103X	MG RESISTOR		
	R2009	NRSA63J-103X	MG RESISTOR		
	R2010	NRSA63J-103X	MG RESISTOR		
	R2011	NRSA63J-223X	MG RESISTOR		
	R2012	NRSA63J-223X	MG RESISTOR		
	R2013	NRSA63J-223X	MG RESISTOR		
	R2014	NRSA63J-223X	MG RESISTOR		
	R2017	NRSA63J-472X	MG RESISTOR		
	R2018	NRSA63J-472X	MG RESISTOR		
	R2021	NRSA63J-331X	MG RESISTOR		
	R2022	NRSA63J-331X	MG RESISTOR		
	R2023	NRSA63J-331X	MG RESISTOR		
	R2024	NRSA63J-331X	MG RESISTOR		
	R2101	NRSA63J-103X	MG RESISTOR		
	R2105	NRSA63J-102X	MG RESISTOR		
	R2107	NRSA63J-104X	MG RESISTOR		
	R2127	NRSA63J-223X	MG RESISTOR		
	R2128	NRSA63J-223X	MG RESISTOR		
	R2129	NRSA63J-223X	MG RESISTOR		
	R2130	NRSA63J-104X	MG RESISTOR		
	R2131	NRSA63J-104X	MG RESISTOR		
	R2132	NRSA63J-103X	MG RESISTOR		
	R2133	NRSA63J-102X	MG RESISTOR		
	R2134	NRSA63J-103X	MG RESISTOR		
	R2135	NRSA63J-222X	MG RESISTOR		
	R2136	NRSA63J-103X	MG RESISTOR		
	R2137	NRSA63J-103X	MG RESISTOR		
	R2138	NRSA63J-223X	MG RESISTOR		
	R2139	NRSA63J-103X	MG RESISTOR		
	R2140	NRSA63J-105X	MG RESISTOR		
	R2157	NRSA63J-104X	MG RESISTOR		
	R2158	NRSA63J-303X	MG RESISTOR		
	R2159	NRSA63J-113X	MG RESISTOR		
	R2171	NRSA63J-105X	MG RESISTOR		
	R2172	NRSA63J-105X	MG RESISTOR		
	R2181	NRSA63J-105X	MG RESISTOR		
	R2182	NRSA63J-105X	MG RESISTOR		
	R2183	NRSA63J-105X	MG RESISTOR		
	R2184	NRSA63J-105X	MG RESISTOR		
	R2186	NRSA63J-105X	MG RESISTOR		
	R2187	NRSA63J-104X	MG RESISTOR		
	R2189	NRSA63J-223X	MG RESISTOR		
	R2201	NRSA63J-103X	MG RESISTOR		
	R2202	NRSA63J-103X	MG RESISTOR		
	R2205	NRSA63J-102X	MG RESISTOR		
	R2206	NRSA63J-102X	MG RESISTOR		
	R2207	NRSA63J-104X	MG RESISTOR		
	R2208	NRSA63J-104X	MG RESISTOR		
	R2221	NRSA63J-333X	MG RESISTOR		

■ **Electrical parts list (DSP board)** **Block No. 05**

⚠	Item	Parts number	Parts name	Remarks	Area
	R2222	NRSA63J-333X	MG RESISTOR		
	R2225	NRSA63J-104X	MG RESISTOR		
	R2226	NRSA63J-104X	MG RESISTOR		
	R2227	NRSA63J-104X	MG RESISTOR		
	R2231	NRSA63J-333X	MG RESISTOR		
	R2232	NRSA63J-333X	MG RESISTOR		
	R2233	NRSA63J-333X	MG RESISTOR		
	R2234	NRSA63J-333X	MG RESISTOR		
	R2235	NRSA63J-333X	MG RESISTOR		
	R2236	NRSA63J-333X	MG RESISTOR		
	R2237	NRSA63J-683X	MG RESISTOR		
	R2238	NRSA63J-683X	MG RESISTOR		
	R2257	NRSA63J-104X	MG RESISTOR		
	R2258	NRSA63J-104X	MG RESISTOR		
	R2261	NRSA63J-104X	MG RESISTOR		
	R2262	NRSA63J-104X	MG RESISTOR		
	R2263	NRSA63J-103X	MG RESISTOR		
	R2264	NRSA63J-103X	MG RESISTOR		
	R2273	NRSA63J-103X	MG RESISTOR		
	R2274	NRSA63J-103X	MG RESISTOR		
	R2275	NRSA63J-682X	MG RESISTOR		
	R2276	NRSA63J-682X	MG RESISTOR		
	R2277	NRSA63J-105X	MG RESISTOR		
	R2278	NRSA63J-105X	MG RESISTOR		
	R2283	NRSA63J-103X	MG RESISTOR		
	R2284	NRSA63J-103X	MG RESISTOR		
	R2285	NRSA63J-113X	MG RESISTOR		
	R2286	NRSA63J-113X	MG RESISTOR		
	R2301	NRSA63J-103X	MG RESISTOR		
	R2302	NRSA63J-103X	MG RESISTOR		
	R2305	NRSA63J-102X	MG RESISTOR		
	R2306	NRSA63J-102X	MG RESISTOR		
	R2307	NRSA63J-104X	MG RESISTOR		
	R2308	NRSA63J-104X	MG RESISTOR		
	R2349	NRSA63J-303X	MG RESISTOR		
	R2350	NRSA63J-303X	MG RESISTOR		
	R2351	NRSA63J-113X	MG RESISTOR		
	R2352	NRSA63J-113X	MG RESISTOR		
	R2353	NRSA63J-222X	MG RESISTOR		
	R2354	NRSA63J-222X	MG RESISTOR		
	R2355	NRSA63J-103X	MG RESISTOR		
	R2356	NRSA63J-103X	MG RESISTOR		
	R2357	NRSA63J-223X	MG RESISTOR		
	R2358	NRSA63J-223X	MG RESISTOR		
	R2359	NRSA63J-103X	MG RESISTOR		
	R2360	NRSA63J-103X	MG RESISTOR		
	R2363	NRSA63J-104X	MG RESISTOR		
	R2364	NRSA63J-104X	MG RESISTOR		
	R2401	NRSA63J-103X	MG RESISTOR		
	R2405	NRSA63J-102X	MG RESISTOR		
	R2407	NRSA63J-104X	MG RESISTOR		
	R2425	NRSA63J-103X	MG RESISTOR		
	R2427	NRSA63J-104X	MG RESISTOR		
	R2429	NRSA63J-103X	MG RESISTOR		
	R2431	NRSA63J-113X	MG RESISTOR		
	R2433	NRSA63J-823X	MG RESISTOR		
	R2485	NRSA63J-102X	MG RESISTOR		
	R2501	NRSA63J-105X	MG RESISTOR		
	R2502	NRSA63J-473X	MG RESISTOR		
	R2503	NRSA63J-473X	MG RESISTOR		
	R2504	NRSA63J-473X	MG RESISTOR		
	R2505	NRSA63J-473X	MG RESISTOR		
	R2506	NRSA63J-473X	MG RESISTOR		

⚠	Item	Parts number	Parts name	Remarks	Area
	R2507	NRSA63J-473X	MG RESISTOR		
	R2508	NRSA63J-473X	MG RESISTOR		
	R2511	NRSA63J-221X	MG RESISTOR		
	R2512	NRSA63J-221X	MG RESISTOR		
	R2513	NRSA63J-221X	MG RESISTOR		
	R2514	NRSA63J-103X	MG RESISTOR		
	R2515	NRSA63J-103X	MG RESISTOR		
	R2516	NRSA63J-103X	MG RESISTOR		
	R2517	NRSA63J-103X	MG RESISTOR		
	R2518	NRSA63J-221X	MG RESISTOR		
	R2519	NRSA63J-221X	MG RESISTOR		
	R2520	NRSA63J-221X	MG RESISTOR		
	R2521	NRSA63J-103X	MG RESISTOR		
	R2522	NRSA63J-103X	MG RESISTOR		
	R2523	NRSA63J-103X	MG RESISTOR		
	R2531	NRSA63F-511X	MG RESISTOR		
	R2532	NRSA63F-102X	MG RESISTOR		
	R2551	NRSA63J-183X	MG RESISTOR		
	R2552	NRSA63J-221X	MG RESISTOR		
	R2553	NRSA63J-221X	MG RESISTOR		
	R2554	NRSA63J-221X	MG RESISTOR		
	R2555	NRSA63J-221X	MG RESISTOR		
	R2557	NRSA63J-221X	MG RESISTOR		
	R2559	NRSA63J-221X	MG RESISTOR		
	R2560	NRSA63J-221X	MG RESISTOR		
	R2561	NRSA63J-112X	MG RESISTOR		
	R2562	NRSA63J-112X	MG RESISTOR		
	R2563	NRSA63J-112X	MG RESISTOR		
	R2564	NRSA63J-750X	MG RESISTOR		
	R2568	NRSA63J-221X	MG RESISTOR		
	R2571	NRSA63J-512X	MG RESISTOR		
	R2572	NRSA63J-512X	MG RESISTOR		
	R2573	NRSA63J-512X	MG RESISTOR		
	R2581	NRSA63J-221X	MG RESISTOR		
	R2582	NRSA63J-221X	MG RESISTOR		
	R2583	NRSA63J-221X	MG RESISTOR		
	R2584	NRSA63J-221X	MG RESISTOR		
	R2585	NRSA63J-221X	MG RESISTOR		
	R2586	NRSA63J-221X	MG RESISTOR		
	R2587	NRSA63J-221X	MG RESISTOR		
	R2589	NRSA63J-221X	MG RESISTOR		
	R2591	NRSA63J-221X	MG RESISTOR		
	R2593	NRSA63J-221X	MG RESISTOR		
	R2594	NRSA63J-221X	MG RESISTOR		
	R2595	NRSA63J-221X	MG RESISTOR		
	R2596	NRSA63J-221X	MG RESISTOR		
	R2597	NRSA63J-102X	MG RESISTOR		
	R2611	NRSA63J-473X	MG RESISTOR		
	R2612	NRSA63J-473X	MG RESISTOR		
	R2613	NRSA63J-473X	MG RESISTOR		
	R2614	NRSA63J-473X	MG RESISTOR		
	R2615	NRSA63J-473X	MG RESISTOR		
	R2616	NRSA63J-473X	MG RESISTOR		
	R2701	NRSA63J-473X	MG RESISTOR		
	R2702	NRSA63J-473X	MG RESISTOR		
	R2703	NRSA63J-473X	MG RESISTOR		
	R2709	NRSA63J-221X	MG RESISTOR		
	R2715	NRSA63J-432X	MG RESISTOR		
	R2716	NRSA63J-221X	MG RESISTOR		
	R2717	NRSA63J-221X	MG RESISTOR		
	R2718	NRSA63J-221X	MG RESISTOR		
	UN560	GP1FA550TZ	OPT TRANSMITTER		
	UN561	GP1FA550RZ	OPT RECEIVER		
	UN562	GP1FA550RZ	OPT RECEIVER		
	UN563	GP1FA550RZ	OPT RECEIVER		
	X 581	NAX0275-001X	1COSCIALLATOR		
	X2501	NAX0308-001X	RESONATOR		
	X2551	NAX0213-001X	CRYSTAL		

■ **Electrical parts list (Micon board)** **Block No. 06**

⚠	Item	Parts number	Parts name	Remarks	Area
⚠	C 1	QCZ9104-472	C CAPACITOR	4700PF	
	C 51	QFLC2AJ-472Z	M CAPACITOR	4700PF 5% 100V	
	C 52	QETM1EM-108	E CAPACITOR	1000MF 20% 25V	
	C 54	QETN1CM-477Z	E CAPACITOR	470MF 20% 16V	
	C 55	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 61	QFLC2AJ-104Z	M CAPACITOR	.10MF 5% 100V	
	C 62	QFLC2AJ-104Z	M CAPACITOR	.10MF 5% 100V	
	C 63	QFLC2AJ-104Z	M CAPACITOR	.10MF 5% 100V	
	C 65	QETM1VM-338	E CAPACITOR	3300MF 20% 35V	
	C 66	QETM1VM-108	E CAPACITOR	1000MF 20% 35V	
	C 68	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C 69	QFLC1HJ-473Z	M CAPACITOR	.047MF 5% 50V	
	C 70	QETN1HM-227Z	E CAPACITOR	220MF 20% 50V	
	C 71	QETN1JM-107Z	E CAPACITOR	100MF 20% 63V	
	C 72	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V	
	C 73	QETN1HM-226Z	E CAPACITOR	22MF 20% 50V	
	C 74	QETN1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
⚠	C 81	QFN82CK-104	M CAPACITOR	.10MF 10% 160V	
	C 91	QCBB1HK-471Y	C CAPACITOR	470PF 10% 50V	
	C 92	QCBB1HK-471Y	C CAPACITOR	470PF 10% 50V	
	C 901	QETN0JM-107Z	E CAPACITOR	100MF 20% 6.3V	
	C 902	QCZ0205-155Z	ML C CAPACITOR	1.5MF	
	C 903	QETN0JM-228Z	E CAPACITOR	2200MF 20% 6.3V	
	C 904	QETN1HM-225Z	E CAPACITOR	2.2MF 20% 50V	
	C 905	QDVB1EZ-223Y	C CAPACITOR		
	C 921	QETN1EM-107Z	E CAPACITOR	100MF 20% 25V	
	C 922	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 931	QETN1EM-107Z	E CAPACITOR	100MF 20% 25V	
	C 932	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 941	QETN1EM-107Z	E CAPACITOR	100MF 20% 25V	
	C 942	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 951	QETN1EM-107Z	E CAPACITOR	100MF 20% 25V	
	C 952	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 961	QETN1EM-107Z	E CAPACITOR	100MF 20% 25V	
	C 962	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 971	QETN1EM-107Z	E CAPACITOR	100MF 20% 25V	
	C 972	QCF31HZ-472Z	C CAPACITOR	4700PF +80:-20%	
	C 975	QETN0JM-477Z	E CAPACITOR	470MF 20% 6.3V	
	C 981	QCBB1HK-331Y	C CAPACITOR	330PF 10% 50V	
	C 982	QCBB1HK-331Y	C CAPACITOR	330PF 10% 50V	
	C 983	QCBB1HK-331Y	C CAPACITOR	330PF 10% 50V	
	C 984	QCBB1HK-331Y	C CAPACITOR	330PF 10% 50V	
	C 985	QCBB1HK-103Y	C CAPACITOR	.010MF 10% 50V	
	C 991	QFLC1HJ-562Z	M CAPACITOR	5600PF 5% 50V	
	C 992	QFLC1HJ-562Z	M CAPACITOR	5600PF 5% 50V	
	C 993	QCBB1HK-101Y	C CAPACITOR	100PF 10% 50V	
	C 994	QCBB1HK-271Y	C CAPACITOR	270PF 10% 50V	
	CN 55	QGD2501C1-03Z	SOCKET		
	CN 56	QGD2501C1-04Z	SOCKET		
	CN 71	QGB2510J1-11	CONNECTOR		
	CN 81	QGB2510J1-09	CONNECTOR		
	CN101	QGB2501J1-12	CONNECTOR		
	CN102	QGB2501J1-04	CONNECTOR		
	CN201	QGB2510J1-11	CONNECTOR		
	CN241	QGB2510J1-12	CONNECTOR		
	CN301	QGB2510J1-14	CONNECTOR		
	CN303	QGB2510J1-13	CONNECTOR		
	CN400	QGF1205C1-10	CONNECTOR		
	CN402	QGF1205C1-08	CONNECTOR		
	CN601	QGB2510J1-07	CONNECTOR		
	CN811	QGA3901F2-03	CONNECTOR		
	CN931	QGD2501C1-04Z	SOCKET		
	CN932	QGD2501C1-03Z	SOCKET		

⚠	Item	Parts number	Parts name	Remarks	Area
⚠	D 51	1SR35-400A-T5	DIODE		
⚠	D 52	1SR35-400A-T5	DIODE		
⚠	D 53	1SR35-400A-T5	DIODE		
⚠	D 54	1SR35-400A-T5	DIODE		
	D 56	MTZJ6.2B-T2	Z DIODE		
	D 57	1SS133-T2	SI DIODE		
⚠	D 61	10E2-FD	DIODE		
⚠	D 62	1SR35-400A-T5	DIODE		
⚠	D 63	10E2-FD	DIODE		
⚠	D 64	1SR35-400A-T5	DIODE		
	D 71	1SR35-400A-T5	DIODE		
	D 72	1SR35-400A-T5	DIODE		
	D 73	1SR35-400A-T5	DIODE		
	D 74	MTZJ33C-T2	Z DIODE		
	D 75	MTZJ8.2C-T2	Z DIODE		
	D 900	1SR35-400A-T5	DIODE		
	D 901	1SR35-400A-T5	DIODE		
	D 902	1SR35-400A-T5	DIODE		
	D 904	1SS133-T2	SI DIODE		
	D 921	MTZJ5.6C-T2	Z DIODE		
	D 931	MTZJ6.2C-T2	Z DIODE		
	D 941	MTZJ5.6C-T2	Z DIODE		
	D 951	MTZJ13C-T2	Z DIODE		
	D 961	MTZJ13C-T2	Z DIODE		
	D 971	MTZJ10C-T2	Z DIODE		
	D 975	1SS133-T2	SI DIODE		
	D 976	1SS133-T2	SI DIODE		
	D 977	1SS133-T2	SI DIODE		
	D 978	1SS133-T2	SI DIODE		
	D 979	1SS133-T2	SI DIODE		
	D 993	1SS133-T2	SI DIODE		
	EP 1	E409182-001SM	GRAND TERMINAL		
	EP 51	QNZ0136-001Z	EARTH PLATE		
	EP 91	E406523-001SM	GND BKT		
	EP901	QNZ0136-001Z	EARTH PLATE		
	FC 1	QNG0020-001Z	FUSE CLIP	F001	
	FC 2	QNG0020-001Z	FUSE CLIP	F001	
	FC 3	QNG0020-001Z	FUSE CLIP	F002	
	FC 4	QNG0020-001Z	FUSE CLIP	F002	
	FC 61	QNG0020-001Z	FUSE CLIP	F061	
	FC 62	QNG0020-001Z	FUSE CLIP	F061	
	FC 63	QNG0020-001Z	FUSE CLIP	F062	
	FC 64	QNG0020-001Z	FUSE CLIP	F062	
	FL991	QQR0590-001	FILTER		
	FL992	QQR0590-001	FILTER		
	FW 51	QUM137-10DGZ4	PARA RIBON WIRE		
	FW831	QUM134-08DGZ4	PARA RIBON WIRE		
	FW881	QUM133-44DGZ4	PARA RIBON WIRE		
	HL901	VYH7237-002	IC HOLDER		
⚠	HS921	E70945-H40B	HEAT SINK		
⚠	HS931	E70945-H40B	HEAT SINK		
⚠	HS941	E70945-H40B	HEAT SINK		
	HS951	E70306-001	HEAT SINK		
	HS961	E70306-001	HEAT SINK		
	HS971	E70306-001	HEAT SINK		
⚠	IC901	MN101C49GHM	IC		
	IC903	IC-PST9139-T	IC		
	J 91	QNS0022-001	JACK		
	O 52	KTD863/Y/-T	TRANSISTOR		
	O 53	KRC105M-T	D TRANSISTOR		
	O 71	KTA1046/Y/	TRANSISTOR		
	O 74	KTC3200/GL/-T	TRANSISTOR		
	O 901	KRC107M-T	D TRANSISTOR		

■ **Electrical parts list (Micon board)** **Block No. 06**

⚠	Item	Parts number	Parts name	Remarks	Area
	O 903	KRC105M-T	D TRANSISTOR		
	O 904	KRC105M-T	D TRANSISTOR		
	O 905	KRC105M-T	D TRANSISTOR		
	O 906	KRC105M-T	D TRANSISTOR		
	Q 907	KRC105M-T	D TRANSISTOR		
	O 908	KRC105M-T	D TRANSISTOR		
⚠	O 921	2SD2395/EF/	TRANSISTOR		
⚠	O 931	2SD2395/EF/	TRANSISTOR		
⚠	O 941	2SD2395/EF/	TRANSISTOR		
	Q 951	2SD2395/EF/	TRANSISTOR		
	O 961	KTA1046/Y/	TRANSISTOR		
	O 971	2SD2395/EF/	TRANSISTOR		
⚠	R 53	QRJ146J-6R8X	UNF C RESISTOR	6.8 5% 1/4W	
	R 54	QRE141J-821Y	C RESISTOR	820 5% 1/4W	
	R 61	QRJ146J-8R2X	UNF C RESISTOR	8.2 5% 1/4W	
	R 72	QRJ146J-332X	UNF C RESISTOR	3.3K 5% 1/4W	
	R 73	QRE141J-223Y	C RESISTOR	22K 5% 1/4W	
	R 74	QRE141J-104Y	C RESISTOR	100K 5% 1/4W	
	R 91	QRL022J-471	UNF OMF RESISTOR	470 5% 1/2W	
	R 92	QRL022J-471	UNF OMF RESISTOR	470 5% 1/2W	
	R 903	QRE141J-331Y	C RESISTOR	330 5% 1/4W	
	R 908	QRE141J-223Y	C RESISTOR	22K 5% 1/4W	
	R 910	QRE141J-223Y	C RESISTOR	22K 5% 1/4W	
	R 911	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 915	QRT022J-8R2	UNF MF RESISTOR	8.2 5% 1/2W	
	R 916	QRT022J-8R2	UNF MF RESISTOR	8.2 5% 1/2W	
	R 921	QRK126J-330X	UNF C RESISTOR	33 5% 1/2W	
	R 922	QRK126J-330X	UNF C RESISTOR	33 5% 1/2W	
	R 923	QRJ146J-272X	UNF C RESISTOR	2.7K 5% 1/4W	
	R 924	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 925	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 926	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 927	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 928	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 929	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 931	QRL017J-430	UNF OMF RESISTOR	43 5% 1/1W	
	R 932	QRL017J-430	UNF OMF RESISTOR	43 5% 1/1W	
	R 933	QRJ146J-272X	UNF C RESISTOR	2.7K 5% 1/4W	
	R 934	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 935	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 936	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 937	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 938	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 939	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 940	QRJ146J-4R7X	UNF C RESISTOR	4.7 5% 1/4W	
	R 941	QRK126J-330X	UNF C RESISTOR	33 5% 1/2W	
	R 942	QRK126J-330X	UNF C RESISTOR	33 5% 1/2W	
	R 943	QRJ146J-272X	UNF C RESISTOR	2.7K 5% 1/4W	
	R 944	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 945	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 946	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 947	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 948	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 949	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 951	QRK126J-120X	UNF C RESISTOR	12 5% 1/2W	
	R 953	QRJ146J-222X	UNF C RESISTOR	2.2K 5% 1/4W	
	R 954	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 955	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 956	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 961	QRK126J-120X	UNF C RESISTOR	12 5% 1/2W	
	R 963	QRJ146J-222X	UNF C RESISTOR	2.2K 5% 1/4W	
	R 965	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 966	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	

⚠	Item	Parts number	Parts name	Remarks	Area
	R 967	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 968	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 969	QRE141J-103Y	C RESISTOR	10K 5% 1/4W	
	R 971	QRJ146J-120X	UNF C RESISTOR	12 5% 1/4W	
	R 973	QRJ146J-332X	UNF C RESISTOR	3.3K 5% 1/4W	
	R 975	QRJ146J-220X	UNF C RESISTOR	22 5% 1/4W	
	R 976	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 977	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 978	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 979	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 980	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 981	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 982	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 983	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 984	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 985	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 986	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 987	QRE141J-221Y	C RESISTOR	220 5% 1/4W	
	R 991	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 992	QRE141J-472Y	C RESISTOR	4.7K 5% 1/4W	
	R 993	QRE141J-622Y	C RESISTOR	6.2K 5% 1/4W	
	R 994	QRE141J-512Y	C RESISTOR	5.1K 5% 1/4W	
	R 995	QRE141J-133Y	C RESISTOR	13K 5% 1/4W	
	R 996	QRE141J-332Y	C RESISTOR	3.3K 5% 1/4W	
	R 997	QRE141J-153Y	C RESISTOR	15K 5% 1/4W	
	R 998	QRE141J-562Y	C RESISTOR	5.6K 5% 1/4W	
⚠	RY 1	QSK0098-001	RELAY		
⚠	T 2	QQT0281-002	POWER TRANSF		
	TA 1	QNZ0079-001Z	TAB		
	TA 2	QNZ0079-001Z	TAB		
⚠	TH 71	QAD0095-4R7Z	POSISTOR		
	X 901	QAX0246-001Z	RESONATOR		

■ **Electrical parts list (Tuner board)** **Block No. 07**

⚠	Item	Parts number	Parts name	Remarks	Area
	AT101	QNB0014-001	ANT TERMINAL		
	BK 1	LV31618-001A	SHIELD BKT		
	C 101	NCB21HK-103X	C CAPACITOR		
	C 103	NCB21HK-223X	C CAPACITOR		
	C 105	NCB21HK-223X	C CAPACITOR		
	C 107	QEKC1CM-226Z	E CAPACITOR	22MF 20% 16V	
	C 111	NCB21HK-473X	C CAPACITOR		
	C 112	NDC21HJ-120X	C CAPACITOR		
	C 113	QCSB1HJ-120Y	C CAPACITOR	12PF 5% 50V	
	C 121	NDC21HJ-120X	C CAPACITOR		
	C 122	NDC21HJ-120X	C CAPACITOR		
	C 123	NCB21HK-473X	C CAPACITOR		
	C 126	NCS21HJ-101X	C CAPACITOR		
	C 128	QENC1HM-474Z	NP E CAPACITOR	.47MF 20% 50V	
	C 129	NCB21HK-102X	C CAPACITOR		
	C 130	QEKC1AM-107Z	E CAPACITOR	100MF 20% 10V	
	C 133	QEKC1CM-226Z	E CAPACITOR	22MF 20% 16V	
	C 134	NCB21HK-222X	C CAPACITOR		
	C 135	NCB21HK-223X	C CAPACITOR		
	C 136	QEKC1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C 137	NCS21HJ-680X	C CAPACITOR		
	C 139	NCB21HK-393X	C CAPACITOR		
	C 140	NCB21HK-393X	C CAPACITOR		
	C 141	NCB21HK-473X	C CAPACITOR		
	C 143	NCB21HK-223X	C CAPACITOR		
	C 144	NCB21HK-473X	C CAPACITOR		
	C 146	QEKC1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C 147	QEKC1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C 148	QEKC1HM-224Z	E CAPACITOR	.22MF 20% 50V	
	C 149	QEKC1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C 150	QEKC1CM-226Z	E CAPACITOR	22MF 20% 16V	
	C 156	QDGB1HK-102Y	C CAPACITOR		
	C 157	NCB21HK-473X	C CAPACITOR		
	C 158	QEKC1CM-226Z	E CAPACITOR	22MF 20% 16V	
	C 161	QEKC1CM-106Z	E CAPACITOR	10MF 20% 16V	
	C 162	QEKC1CM-106Z	E CAPACITOR	10MF 20% 16V	
	C 163	NCB21HK-223X	C CAPACITOR		
	C 164	NCB21HK-473X	C CAPACITOR		
	C 168	QEKC1HM-105Z	E CAPACITOR	1.0MF 20% 50V	
	C 184	QEKC1CM-107Z	E CAPACITOR	100MF 20% 16V	
	C 185	QEKC1CM-106Z	E CAPACITOR	10MF 20% 16V	
	C 186	QEKC1CM-106Z	E CAPACITOR	10MF 20% 16V	
	C 191	NCS21HJ-820X	C CAPACITOR		
	C 192	NCS21HJ-470X	C CAPACITOR		
	C 193	NCB21HK-561X	C CAPACITOR		
	C 194	NCB21HK-104X	C CAPACITOR		
	C 195	NCB21HK-331X	C CAPACITOR		
	C 196	QEKC1HM-225Z	E CAPACITOR	2.2MF 20% 50V	
	C 197	NCB21HK-473X	C CAPACITOR		
	C 199	QEKC1CM-106Z	E CAPACITOR	10MF 20% 16V	
	CF101	QAX0285-001Z	C FILTER		
	CF102	QAX0285-001Z	C FILTER		
	CF103	QAX0519-001Z	C FILTER		
	CN111	QGB2501K2-12	CONECTOR		
	CN112	QGB2501K1-04	CONNECTOR		
	D 121	1SS133-T2	SI DIODE		
	D 123	1SS133-T2	SI DIODE		
	D 129	1SS133-T2	SI DIODE		
	D 131	1SS133-T2	SI DIODE		
	IC102	LA1838	IC		
	IC121	LC72136N	IC		
	IC191	SAA6588	IC(RDS)		
	L 112	QQL231K-2R7Y	INDUCTOR		

⚠	Item	Parts number	Parts name	Remarks	Area
	O 102	2SC535/BC/-T	TRANSISTOR		
	O 103	2SC461/BC/-T	TRANSISTOR		
	O 111	KTC3199/GL/-T	TRANSISTOR		
	O 112	KTC3199/GL/-T	TRANSISTOR		
	Q 113	DTA114YKA-X	TRANSISTOR		
	O 121	KRA103M-T	TRANSISTOR		
	R 103	NRSA02J-221X	MG RESISTOR		
	R 104	NRSA02J-272X	MG RESISTOR		
	R 105	NRSA02J-391X	MG RESISTOR		
	R 106	NRSA02J-102X	MG RESISTOR		
	R 107	NRSA02J-561X	MG RESISTOR		
	R 108	NRSA02J-332X	MG RESISTOR		
	R 109	NRSA02J-221X	MG RESISTOR		
	R 111	NRSA02J-182X	MG RESISTOR		
	R 112	QRE141J-182Y	C RESISTOR	1.8K 5% 1/4W	
	R 114	NRSA02J-272X	MG RESISTOR		
	R 115	NRSA02J-104X	MG RESISTOR		
	R 119	NRSA02J-103X	MG RESISTOR		
	R 122	NRSA02J-472X	MG RESISTOR		
	R 124	NRSA02J-222X	MG RESISTOR		
	R 126	NRSA02J-562X	MG RESISTOR		
	R 127	NRSA02J-822X	MG RESISTOR		
	R 128	NRSA02J-472X	MG RESISTOR		
	R 129	NRSA02J-222X	MG RESISTOR		
⚠	R 130	QRZ9005-680X	F RESISTOR	68 1/0W	
	R 132	NRSA02J-393X	MG RESISTOR		
	R 133	NRSA02J-392X	MG RESISTOR		
	R 134	NRSA02J-102X	MG RESISTOR		
	R 140	NRSA02J-473X	MG RESISTOR		
	R 141	NRSA02J-102X	MG RESISTOR		
	R 142	NRSA02J-470X	MG RESISTOR		
	R 143	NRSA02J-562X	MG RESISTOR		
	R 144	NRSA02J-332X	MG RESISTOR		
	R 145	NRSA02J-103X	MG RESISTOR		
	R 146	NRSA02J-472X	MG RESISTOR		
	R 147	NRSA02J-332X	MG RESISTOR		
	R 150	NRSA02J-331X	MG RESISTOR		
	R 157	NRSA02J-332X	MG RESISTOR		
	R 158	NRSA02J-332X	MG RESISTOR		
	R 161	NRSA02J-102X	MG RESISTOR		
	R 162	NRSA02J-102X	MG RESISTOR		
	R 182	NRSA02J-103X	MG RESISTOR		
	R 183	NRSA02J-103X	MG RESISTOR		
	R 184	NRSA02J-103X	MG RESISTOR		
	R 191	NRSA02J-102X	MG RESISTOR		
	R 192	NRSA02J-474X	MG RESISTOR		
	R 193	NRSA02J-103X	MG RESISTOR		
	R 194	NRSA02J-103X	MG RESISTOR		
	RF101	QAU0119-001	FRONT END	FOR FTZ	
	T 111	QQR0871-001	COIL BLOCK		
	T 142	QQR0973-001	IFT		
	X 121	QAX0402-001	CRYSTAL		
	X 191	QAX0263-001Z	CRYSTAL		

< MEMO >

Packing materials and accessories parts list

Block No. M 2 M M

Block No. M 3 M M



■ Parts list (Packing)

Block No. M2MM

⚠	Item	Parts number	Parts name	Q'ty	Description	Area
	P 1	QPA02503505P	POLY BAG	1	FOR INST	
	P 2	LV20989-011A	PACKING CASE	1	RX-8010RBK	
		LV20989-014A	PACKING CASE	1	RX-8012RSL	
	P 3	LV20947-001A	PACKING PAD	1		
	P 4	LV20948-001A	PACKING PAD	1		
	P 5	LV32034-003A	SHEET	2		
	P 6	QPC06507015P	POLY BAG	1	FOR SET	

■ Parts list (Accessories)

Block No. M3MM

⚠	Item	Parts number	Parts name	Q'ty	Description	Area
	A 1	RM-SRX8010R	REMOCON	1	RX-8010RBK	
		RM-SRX8012R	REMOCON	1	RX-8012RSL	
	A 2	----------	BATTERY	2		
	A 3	LVT0618-006A	INST BOOK	1	SWE, FIN, DAN, GER	EN
		LVT0618-006A	INST BOOK	1	FRE, SPA, ITA	EN
		LVT0618-005A	INST BOOK	1	FRE, GER, DUT	E
	A 4	EWP503-001C	ANT.WIRE	1		
	A 5	QAL0204-001	AM LOOP ANT	1		
	A 6	BT-54008-2	WARRANTY CARD	1		EN
		BT-54013-1	WARRANTY CARD	1		E